








Pressurized container. Read back panel before use.

WARNING:

CHOKING HAZARD-Small parts. Not for children under 3 years.








TO LOAD CAN INTO ENERGY BEAM BLASTER (sold separately):

- 1. Slide lock in direction shown.
- 2. Open door.
- 3. With top of canister pointing toward front of tov. insert bottom of canister into compartment. Then, insert rest of canister into compartment. Turn canister so that red mark on top of canister is facing top of tov.
- 4. Close cover.
- 5. To operate, squeeze trigger,

TO ATTACH MANUAL DISPENSER TO CAN:

To spray string directly from the canister (without the gun), snap the manual dispenser onto the top of the canister as shown.





WARNING:

Contents Under Pressure. Do Not Puncture Or Incinerate. Do Not Expose to Heat or Store at Temperatures above 120 Degrees F. Do Not Spray on Open Flame or Any Hot Stoves or ht Bulbs. Do Not Leave in Direct Sunlight or Store in a Hot Vehicle. Heat Čan Cause Can to Burst Violently. Do Not Spray in Eyes or Face. lot Ingest String



CAUTION:

Do not spray on walls, floors, clothing, furniture or vinyl as string may stain certain types of surfaces and fabrics. USE ONLY AS DIRECTED.

Shake well before using. Can should be used in a horizontal position.

Adult Supervision Required. Conforms to ASTM D4236. Non-Toxic. Non-Flammable. Not Recommended for Indoor Use.



Some poses may require additional support. Product and colors may vary.

© 2005 Lucasfilm Ltd. & ® or TM where indicated. All rights reserved.
Used under authorization.

© and/or TM & © 2005 Hasbro.

© denotes Reg. U.S. Pat. & TM Office.

Ingredients: Water HFC 134a (propellant), Acrylic Resin, Hydrocarbon solvents, Light oil, Pigment.

P/N 6449090000

