

ULTIMATE LIGHTSABER

CHOOSE YOUR DESTINY!

For more toy information

For more toy information visit: www.starwars.hasbro.com

© 2005 Lucasfilm Ltd. & @ or TM where indicated. All Rights Reserved. ®* and/or ^{TM*} & © 2005 Hasbro. All Rights Reserved. TM & @ denote U.S. Trademarks.





Not suitable for children under 3 years because of small parts - choking hazard.



STAR BARS

ULTIMATE LIGHTSABER



CHOOSE YOUR DESTINY!

Requires 2 x 1.5V"C" or R14 batteries (not included). Alkaline batteries recommended. Phillips/cross head screwdriver (not included) needed to replace light bulb.

84850

AGES 6+

CUSTOMIZE


THE ABOVE STEPS ARE THE BASIC STEPS FOR BUILDING A LIGHTSABER. EACH JEDI CHANGES HIS OR HER LIGHTSABER TO GIVE IT A DISTINCTIVE LOOK. USE THE OTHER PARTS TO CUSTOMIZE YOUR LIGHTSABER!

SOME IDEAS:

- ADD SLEEVE RINGS
- · ADD A SWITCH
- CHANGE THE CRYSTAL
- · CHANGE THE FILTER
- CHANGE THE SLEEVE
- · CHANGE THE BLADE
- CREATE A DOUBLE BLADED LIGHTSABER [REMOVE THE CAP AND ATTACH THE ADAPTER. ATTACH THE OTHER BLADE TO THE ADAPTER].

POWER UP!


AS A NEW JEDI, YOU MUST PRACTICE YOUR DUELING SKILLS. PRESS THE BUTTON TO "POWER UP" YOUR LIGHTSABER.



WHEN CUSTOMIZING YOUR LIGHTSABER, ALWAYS MAKE SURE THE BUTTON IS EXPOSED SO THAT YOU CAN "POWER UP"!

MORE LIGHTSABER LOOKS


YOU CAN ALSO CHANGE YOUR LIGHTSABER TO MAKE IT LOOK LIKE ONE USED BY A STAR WARS® CHARACTER. HERE ARE SOME IDEAS:



LIGHTING SOURCE REPLACEMENT

HERE ARE THE INSTRUCTIONS FOR REPLACING THE LIGHTING SOURCE IN YOUR LIGHTSABER.

TO REPLACE LIGHT BULB: ADULT REPLACEMENT OF LIGHT BULB REQUIRED. USING A PHILLIPS/CROSS HEAD SCREWDRIVER (NOT INCLUDED), UNSCREW THE LIGHT BULB HOLDER FROM THE LIGHT TUBE COLLAR AND TAKE IT APART TO REPLACE THE BULB WITH A PR4 [2.3V] LIGHT BULB.




STEP '

THE FIRST STEP IN BUILDING A LIGHTSABER IS TO INSTALL THE POWER-GENERATING COMPONENT.

INSTALLING BATTERIES

INSERT 2 X 1.5V "C" OR R14 BATTERIES INTO HILT. ALKALINE BATTERIES RECOMMENDED.





CAUTION:

TO AVOID BATTERY LEAKAGE

- Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- 2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- 3. Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.




CAUTION:


- Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
- 2. Do not mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
- 3. Remove exhausted or dead batteries from the product.
- 4. Remove batteries if product is not to be played with for a long time.
- 5. Do not short-circuit the supply terminals.
- Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
- RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.


FCC Statement:


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.









STEP 6


STEP


7

BUSTOMIZE



NOTE: LINE UP RIB WITH SLOT ON HILT. FITS TWO WAYS. WHEN CUSTOMIZING YOUR LIGHTSABER, ALWAYS MAKE SURE THE BUTTON IS EXPOSED SO THAT YOU CAN "POWER UP"!





FINISHED! Congratulations! You have a

STEP

9

CONGRATULATIONS! YOU HAVE ASSEMBLED YOUR LIGHTSABER AND ARE READY TO CHOOSE YOUR DESTINY!

GREETINGS, PADAWAN! YOU ARE ABOUT TO TAKE YOUR FINAL STEP ON THE PATH TO BECOMING A JEDI KNIGHT OR MYSTICAL SITH APPRENTICE. ONLY THOSE WHO ARE POWERFUL IN THE WAYS OF THE FORCE CAN SUCCESSFULLY BUILD A LIGHTSABER. IT REQUIRES GREAT SKILL AND MASTERY OF THE FORCE. ARE YOU READY? THEN BEGIN, AND MAY THE FORCE BE WITH YOU!

