


STAR WARS®

AGES 4+
86670/85173 Asst.




WARNING:

**CHOKING HAZARD—Small parts.
Not for children under 3 years.**



TO ASSEMBLE WEAPON:
Assemble weapon as shown.



TO FIRE WEAPON:
1. Insert missile.
2. Push button to fire.



Product and colors may vary.
© 2005 Lucasfilm Ltd. & © or TM where indicated.
All rights reserved.
®* and/or TM* & © 2005 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.

For more toy information visit:
www.starwars.hasbro.com



starwars.com

P/N 6507920000