



**Ages 3 & Up**

# SALEM the Cat

## SALEM the Cat Phrases:

“Harvey & Sabrina, Harvey & Sabrina!”


“I urge you to worship me!”

“Can opener... Gotta go!”


“Please be tuna!”

## To Replace Batteries:


1. Remove battery pack from toy. Loosen screw in battery pack door and remove door (screw will remain attached to door).



2. Remove exhausted batteries. Insert 3 fresh “AAA” batteries (alkaline recommended) into battery pack as shown. Replace battery door and tighten screw.



3. Replace battery pack inside toy with front of pack facing cat's chest.



## CAUTION: TO AVOID BATTERY LEAKAGE

1. As with all small batteries, the batteries included with this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect.
2. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions.
3. Do not mix old batteries and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
4. Always remove exhausted or dead batteries from the product.

## FCC STATEMENT

“This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.”

Product and colors may vary.

TM Archie Comic Publications, Inc.

© 1997 Viacom Productions, Inc. All Rights Reserved. Hasbro Toys, Authorized User.

Manufactured and distributed by Hasbro, Inc. Pawtucket, RI 02862 USA.

KENNER® is a trademark of Hasbro, Inc.

© denotes Reg. U.S. Pat. & TM Office.

**MADE IN CHINA.**

28908

P/N 472827