

## TO MAKE CANDY ICE-POPS...

1. Use a mold with a *large* top to make ice-pops. Follow the previous steps 1-7 to make the candy creation.
2. Fill a small cup with tap water. Use the dropper to draw water from the cup. Place tip of dropper into hole in mold top, and slowly squirt water into the mold until mold is completely full. Seal hole with plug.

**Note:** *Be sure to remove candy mold from Spinnin' Sam before adding water.*

3. Place candy mold in freezer for about 30 minutes, or until water is completely frozen. Remove from freezer and run under warm water for about 10 seconds, to help loosen ice-pop from the mold top.
4. Fit tip of ice-pop stick into mold bottom. Remove plug from mold top. Grasp mold bottom and gently pull off mold top. Now you can enjoy your own ready-to-eat ice-pop treat!

## TO CHANGE BATTERY...

Remove battery compartment cover by inserting tip of small screwdriver or edge of coin into slot. Then, lift cover and remove. (For battery installation, see TO INSTALL BATTERY...)

**CAUTION:** Always remove exhausted or dead battery from the product. Remove battery if storing for a long period of time.

## PLEASE NOTE:

Molds are reusable. Be sure to clean Spinnin' Sam's parts before each use.

To keep Spinnin' Sam clean, periodically use a damp paper towel to wipe exposed surface areas.

**NONTOXIC CONFORMS TO ASTM D-4236**

Product and colors may vary.

Candy manufactured for Hasbro, Inc.

Product: © 1996 Hasbro, Inc., Pawtucket, RI 02862 USA. All Rights Reserved.

® denotes Reg. U.S. Pat. & TM Office. U.S. Patent Pending.

**CANDY MADE IN USA. ALL OTHER COMPONENTS MADE IN CHINA. PACKAGED IN CHINA.**



**WARNING:**

CHOKING HAZARD - Small parts.  
Not for children under 3 years.

TM

Ages 4 & Up  
65051

# Spinnin' Sam


He twirls up a treat that's yummy to eat!

REQUIRES 1 "D" BATTERY (NOT INCLUDED; ALKALINE RECOMMENDED).  
FOOD INGREDIENTS: 26 PACKETS OF POWDERED CANDY; TOTAL NET WT. 2.7 OZ. (78 g). 3 PACKETS OF PELLET CANDY; TOTAL NET WT. 1.6 OZ. (45 g).  
Includes Spinnin' Sam, cover, mold spinner, 26 packets of powdered candy mix, 3 packets of pellet candy, 3 ice-pop sticks, 6 candy molds (tops and bottoms), 6 mold plugs and dropper.


Thank you for purchasing Spinnin' Sam, the fun, easy-to-use toy that lets kids make delicious candy designs and ice-pops!  
For maximum enjoyment of this product, please read and follow the instructions carefully. If you have any questions, comments, or need additional information concerning this product or its parts,

please call our

Hasbro Consumer Service  
hotline at 1-800-327-8264,  
Monday through Friday,  
8:00 AM to 5:00 PM  
Eastern Time.




© 1996




**TO INSTALL BATTERY...**

- Insert 1 "D" battery (alkaline recommended) into battery compartment as indicated.
- Fit battery compartment cover onto battery compartment as shown, then slide it forward until it snaps into place.



Spinnin' Sam makes tasty treats that you'll love to eat! There are seven fun flavors to choose from:

- Fruit Punch
- Green Apple
- Cherry
- Grape
- Lemonade
- Marshmallow
- Chocolate





**BEFORE BEGINNING:**

wash molds, ice-pop sticks, plugs, dropper and mold spinner.


**TO MAKE CANDY CREATIONS...**

1. Select a candy mold top and bottom. Press top onto bottom as shown (1a). Note: Candy mold tops are clear and come in small and large sizes. Large tops are used to make ice-pops (see TO MAKE CANDY ICE-POPS...)




- 1) If you are using a candy mold with a small top, place the mold spinner into Spinnin' Sam's mouth, with the side marked "small" facing up as shown; or 2) If you are using a candy mold with a large top, place the mold spinner in with the side marked "large" facing up.
3. Place assembled candy mold onto mold spinner as shown.

**MOLD SPINNER**




**COVER**



4. Fit cover into Spinnin' Sam's mouth, aligning notches on cover with tabs in mouth.

5. Turn cover counterclockwise to make the mold spinner spin. It may be easiest for a child to move the tongue on the cover to start the spinning action.

6. Tear off corner of candy packet and pour powdered candy through the holes in cover and mold top. Create a colorful candy creation by adding different flavors to the candy mold, or by sprinkling in some of the pellet candy.
7. When candy mold is filled with candy, turn cover clockwise to its original position. After design shape has stopped spinning completely, remove the cover and the completed candy creation.



8. If you wish to display your new creation, seal the hole in the mold with a plug. If you can't resist eating the candy right away, just pour it right out of the mold!