

# COLOR CHANGE SPIROGRAPH<sup>®</sup>



**WARNING:**

CHOKING HAZARD - Small parts.  
Not for children under 3 years.

Unique designs with a magical color surprise!

Thank you for purchasing Spirograph, the classic design toy that has captivated and delighted young artists for over 30 years. For maximum enjoyment of this product, please read and follow the instructions carefully. If you have any questions, comments, or need additional information concerning this product or its parts, please call our Hasbro Consumer Service hotline at 1-800-327-8264, Monday through Friday, 8:00 AM to 5:00 PM Eastern Time.

Includes: 13 Gears, 2 Gear Rings, 1 Square Ring, 1 Propeller Gear, 1 Ring Holder, 1 Color Change Pen, 8 Sheets of Color Change Paper, 6 Sheets of White Paper and Storage Tray.

## FOR COLOR CHANGE SPIROGRAPH DESIGNS

Use the special pen and colored paper to create exciting Spirograph designs that actually change color before your eyes!


- With yellow paper, the design turns purple!
- When you use purple paper, the design turns green!
- Try the blue paper...the design turns yellow!
- And if the paper is green, the design turns yellow!

### Please note:


The color change pen will not work on white paper. To avoid possibility of damage to tip of color change pen, do not use excessive force when drawing.

## IT'S EASY TO MAKE A SPIROGRAPH DESIGN!


(If you are using the ball point pen for this design, be sure to rub the point on a piece of scrap paper until the ink flows smoothly before beginning.)



1. The holder is used to keep the rings and propeller shape in place while you draw the designs. Place a sheet of paper over the holder with pegs facing up. Press down on the paper to punch the pegs through as shown.



2. Select a ring for this design. Line up holes in ring with pegs and place ring onto paper, with pegs through holes to keep ring in place.



3. Select a gear and place it inside the ring so that teeth on gear and ring are engaged. Put the tip of the pen into one of the gear holes. With one hand, hold the ring down to secure it on the paper. (If you are using color change paper, be sure to avoid pressing on it with your hands or fingers because the paper might smear.)

With your other hand, hold the pen upright and use it to carefully move the gear around the inside of the ring. Always keep the teeth on the gear and ring engaged as you draw. Draw around the ring until the line returns to the point where you started. Now, take a look at the Spirograph pattern you've just created!


## YOU CAN MAKE ALL KINDS OF EXCITING DESIGNS!

With your imagination and the parts in this set, you can make an endless number of creative Spirograph designs! For your own unique patterns, place your pen in any of the numbered gear holes and start drawing! For more detailed designs you can alternate the gear holes you use, and even add different gears to the same design!


### ***Below are just a few of the designs that you can create.***

**Note:** If you are making a design around the outside of the ring or propeller shape, then place the holder at or near the center of the paper to allow you to make designs that will not run off the edge of the paper.


**FOR A COMPLETE DESIGN, DRAW AROUND THE RING UNTIL THE LINE RETURNS TO THE POINT WHERE YOU STARTED.**




RING #150/105 (Inside)  
STEP 1: GEAR #60  
(gear hole 16)  
STEP 2: GEAR #60  
(gear hole 3)




RING #150/105 (Inside)  
STEP 1: GEAR #45  
(gear hole 4)  
STEP 2: GEAR #45  
(gear hole 13)




SQUARE RING (Inside)  
GEAR #60 (gear hole 1)



RING #150/105 (Inside)  
GEAR #48 (gear hole 2)



RING #150/105 (Inside)  
GEAR #72 (gear hole 13)



RING #144/96 (Inside)  
GEAR #45 (gear hole 16)

NONTOXIC CONFORMS TO ASTM-D-4236

©1995 Hasbro, Inc., Pawtucket, RI 02862 U.S.A. All Rights Reserved.

® denotes Reg. U.S. Pat. & TM Office

MADE IN MEXICO.

67003 P/N 46339401

**Kenner®**