




INSTRUCTIONS


1 CONTROL GUIDE

LASER BLASTER




STORMTROOPER

"It's them - blast 'em." "Move Along"



BACK VIEW



FRONT VIEW

2 INSERTING THE BATTERIES

The Stormtrooper Room Alarm and Laser Target requires a total of five (5 X 1.5V) "AAA" or "LR03" alkaline batteries. Two (2 X 1.5V) "AAA" or "LR 03" batteries for the Remote Control and three (3 X 1.5V) "AAA" or "LR03" batteries for the Alarm.



INSTALLATION & REPLACEMENT:


Carefully loosen the battery door screws and remove the battery door. Install or replace the "AAA" alkaline batteries and orient to "+" and "-" as indicated. Replace the battery door and carefully tighten the screws. Do not over tighten as this may cause damage.

TO ENSURE PROPER FUNCTION :


- Do not mix old and new batteries.
- Do not mix alkaline, standard or rechargeable batteries.
- Battery installation should be done by an adult.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).

- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

REMOTE CONTROL




ALARM



3 OPERATION INSTRUCTION


SETTING UP:

Your Stormtrooper personal alarm is designed to detect very small changes in heat. It is important to know that the Heat Sensor is set up to detect intruders that approach directly to the side of the Alarm unit, not to the front. You can stand the stormtrooper on any flat surface. Rotate the Stormtrooper so that the Sensor Lens faces the direction desired for the Intruder Detection Area. See the diagrams below to further understand how to position your Alarm Unit.



ALARM :

Switch the Alarm "On" with the "On/Off" switch located on the back of the Alarm unit. The red Alarm Indicator Lights will show solid red when switched on and the alarm is now set. Don't forget to turn the Alarm off when not in use to preserve your battery life.



BACK VIEW

SOUND:


Select one of the built-in Alarm sounds by pushing a Sound Selector Button (1) laser blast (2) it's them - blast 'em," or (3) "Move Along". You will hear a brief sample of the sound you have selected. You can change your mind if you want, as only the last sound selected/sampled will be heard in case of an intruder.

4 INSTRUCTIONS CONTINUED

NOTE:

You can put your Alarm on a shelf or table but if you lay it flat on its back, it will severely reduce the intruder detection range. For best results, stand the Alarm up, close to the edge of any flat surface and turn it to the desired detection direction.

Remote works best from the Sensor Lens side or directly in front.




Remote Control -
up to 8 feet range
from this side.

Remote works best from this side or directly in front. A direct line to the sensor lens is required for best results.

ACTIVATION:

Enable Alarm by sliding the switch to "Alarm". This indicates that your Alarm is ready to detect intruders. Set the Intruder Detection Area to the desired direction.



Alarm - up to 4 feet
range to this side

INTRUDER:

An intruder entering the Intruder Detection Area (up to 4 feet range to the side, see above) will trip the Alarm. The selected Alarm Sound will be heard. The sound will then stop and the Alarm will reset itself and be ready for the next intruder.

NOTE DETECTION AREA DIRECTION:

Rotate the Alarm to the desired position to customize the direction of the intruder detection area. While sitting on a table or flat surface, just point the lens in the desired direction. A few trial activations will help you decide upon the direction that is just right. Note that the detection area extends to the side of the Alarm as indicated above and does not detect intruders approaching directly from the front or from the other side.

LASER TARGET:

You can use your Stormtrooper Room Alarm as a Laser Target to practice your aim. To activate the target function, switch the control switch to GAME. Then, using your laser blaster aim at the sensor on the belt of the Stormtrooper. If your aim is good the Stormtrooper will respond with laser blasts. Note that the range of the game is 10 feet.

5 90-DAY LIMITED WARRANTY

Tiger Electronics, Inc. (Tiger) warrants to the original consumer purchaser of this product that the product will be free from defects in materials or workmanship for 90 days from the date of original purchase. This warranty does not cover damages resulting from accident, negligence, improper service or use or other causes not arising out of defects in materials or workmanship.

During this 90-day warranty period, the product will either be repaired or replaced (at Tiger's option) without charge to the purchaser, when returned with proof of the date of purchase to either the dealer or to Tiger.

Product returned to Tiger without proof of the date of purchase or after the 90-day warranty period has expired, but prior to one year from the original date of purchase, will be repaired or replaced (at Tiger's option) for a service fee of U.S.\$12.00. Payments must be by check or money order payable to Tiger Electronics, Inc.

To purchase a REMOTE CONTROL unit due to loss or breakage, please send a \$5.00 check or money order made payable to Tiger Electronics, Inc. to the address and department listed below. Please be sure to indicate this is for the "STORMTROOPER ROOM ALARM REMOTE" with your payment.

The foregoing states the purchaser's sole and exclusive remedy for any breach of warranty with respect to the product.

All product returned must be shipped prepaid and insured for loss or damage to:

Tiger Electronics, Inc. Repair Dept.
980 Woodlands Parkway
Vernon Hills, Illinois 60061, U.S.A.

The product should be carefully packed in the original box or other packing materials sufficient to avoid damage during shipment. Include a complete written description of the defect, a check if product is beyond the 90-day warranty period, and your printed name, address and telephone number.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE TIGER IN ANY WAY. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE NINETY (90) DAY PERIOD DESCRIBED ABOVE. IN NO EVENT WILL TIGER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE, OR MALFUNCTION OF THIS TIGER PRODUCT.

For more information about Tiger Electronics, our products and special promotions, please visit our web site at www.tigertoys.com.

Star Wars TM & © 1997 Lucasfilm Ltd.
All Rights Reserved
Used Under Authorization

©, TM, & © 1997 Tiger Electronics, Inc.
All Rights Reserved
980 Woodlands Parkway
Vernon Hills, Illinois 60061, U.S.A.
www.tigertoys.com

8808101WTE-01