

69591




AGES 4 AND UP

WARNING:
CHOKING HAZARD—Small parts
Not for children under 3 years.

SWOOP™ WITH SWOOP TROOPER



LABEL APPLICATION

1. Apply labels using the numbers on the label sheet and these illustrations as a guide.



ASSEMBLY


2A. Assemble the two parts of the nose piece.




2B. Then insert the front arms of the vehicle into the assembled nose piece. Lower the arms to snap them into the nose piece.

OPERATION


3. The wings can be raised or lowered as you wish.




4. Load a missile into the launcher. Press the button to fire.



5. Seat included figure at the controls. His hands fit around the handles.



6. Raise the landing gear for pretend flight.



Kenner®

© & © 1996 HASBRO, INC.
Pawtucket, Rhode Island 02862
All Rights Reserved.
© & © 1996 Lucasfilm Ltd.
All Rights Reserved.
Used Under Authorization.
MADE IN CHINA.