

SUPERCHARGER 400 SPECIFICATIONS

SIZE: 16 1/4" X 8 1/2"	WATER CAPACITY: 24 1/4 OZ.
WEIGHT EMPTY: 20 OZ.	WEIGHT FILLED: 44 1/4 OZ.
PRESSURE: 35 PSI	PUMP STROKE: 6 3/4"

**AIR PRESSURE SUPER
SOAKER.**

WATER RESERVOIR

NOZZLE

HAND PUMP

TRIGGER




SUPER CHARGER™

400


©1998 LARAMI LIMITED, A subsidiary of Hasbro, Inc.
Mt. Laurel, NJ 08054. Made in China. Conforms with 15 CFRs 1150-3.
For questions or comments call: 1-800-669-TOYS.

LARAMI


TO OPERATE USING CHARGER:



1. Attach fast-fill charger to your garden hose. Turn on water **AFTER** you attach charger. For better results, pump 5 times before charging from hose charger.



2. Press nozzle into charger. Relief Valve will release water when Super Soaker[®] is full.



3. Pull the trigger to release a powerful stream of water. Or pull and release trigger rapidly for more shots.

TO OPERATE USING ANY WATER SOURCE:

1. Unscrew bottle. Fill water tank 2/3 full with clean, clear tap water. Replace bottle.
2. Pump hand pump 16 to 20 times to build up pressure.
3. For maximum performance, pump a few times after each shot.

TROUBLESHOOTING CHART

SUPER CHARGER™ 400	Bottle out of water	Super Soaker [®] not pressurized	Bottle not screwed all the way in	This is normal	Intake screen on pick up tube is clogged	O-ring inside bottle is missing
	Refill bottle 2/3 full	Pump 16-20 times	Screw bottle until snug. Don't overtighten.	Sounds are valves operating	Clean screen	Do not lose O-ring
1. Super Soaker [®] does not shoot.	●	●	●			●
2. Super Soaker [®] does not shoot far.		●	●		●	●
3. Super Soaker [®] makes noise while pumping.				●		
3. Super Soaker [®] leaks around bottle neck.			●			●

DO'S AND DON'TS

- 1 Do not shoot at any-one's face or eyes.
- 2 Do not leave Super Soaker[®] pressurized when not in use. Pull trigger until all pressure is released. Remove water from reservoir.
- 3 Fill your Super Soaker[®] with clean, clear tap water only. Use of other water or liquids may be harmful or damage the Super Soaker[®].
- 4 Do not insert any objects other than nozzle into charger.