


AQUAPACK DEVASTATOR™ Backpack Instructions



1 Place backpack straps over both shoulders as you would a standard backpack.



2 Adjust both straps until snug.



3 Snap together chest strap until it firmly clicks into place.

Water Supply Instructions



1 Undo attached strap.




2 Place end of standard garden hose into Quick Fill Cap. Press down and fill with clean, clear water.



3 Carefully watch Water Gauge to determine when backpack is full.




4 Once the Water Gauge has reached its maximum capacity, remove hose from Quick Fill Cap.




5 Put attached strap back.

Blaster Instructions



1 Pump 20 to 25 times to pressurize.



2 Pull trigger to blast out powerful constant streams of water.

Body Target Instructions



1 Remove Body Target paper backing and dispose of properly.



2 Stick adhesive side of Body Target onto your body and blast away!

IMPORTANT: SUPER SOAKER SOAKERTAG ELITE Body Targets have been thoroughly tested. However, as with cosmetics, some individuals may experience minor irritation. If irritation occurs, rinse with water and discontinue use.