
## HYDROBLADE" Instructions



Place end of hose/faucet into Quick Fill Cap. Press down and pressurize. fill 2/3 with clean, clear water.



Pump 15 to 20 times to

Pull trigger to release water.

Press HYDROBLADE Action Button to engage the Blade.



Pull trigger to release water in every direction.

## **Body Target Instructions**



Remove Body Target paper backing and dispose of properly.



Stick adhesive side of Body Target onto your body and blast away!

IMPORTANT: SUPER SOAKER SOAKERTAG ELITE Body Targets have been thoroughly tested. However, as with cosmetics, some individuals may experience minor irritation. If irritation occurs, rinse with water and discontinue use.