



PLEASE NOTE:

- Remove batteries from plastic bag and discard bag IMMEDIATELY.
- Batteries should be inserted or replaced by ADULTS ONLY.

Instructions



TO INSERT BATTERIES:

1. Remove doll's outfit. Remove screw from battery compartment cover using a Phillips® screwdriver (not included). Remove cover.
2. Insert 3 A-76 button cell batteries (included) into battery compartment as shown. Replace cover. Insert and tighten screw. Dress doll in her outfit.

CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturer's instructions.
2. Never mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
3. Always remove exhausted or dead batteries from the product.

HOW TO MAKE YOUR DOLL TALK:

Press the place on your doll's chest where her heart is. When you press her heart, she says something special to you!

- Betty Bye™ says "Nite-nite!"
- Cuddly Carly™ says "Love you!"
- Sweetie Sarah™ says "Kiss me!"
- Little Marissa™ says "Mama!"

CAUTION: Do not immerse doll in water.



9009 Asst.

©1991 Hasbro, Inc., Pawtucket, RI 02862 U.S.A. All Rights Reserved. P/N 42298200