

THIN tronix™

One size fits

one style does not

Welcome to a new world
of technology - THIN-TRONIX™.

Energy. Music. Communication. Expression.

THIN-TRONIX™ technology has been developed
to fit your lifestyle needs, combining breakthrough
technology with ultra cool shapes and colorful designs.



Energy • Music • Communication • Expression

Instructions

1. To activate battery remove TAB on side
2. Press Display will flash. Press again, and month will show.
3. Press to set the month. Press to enter day setting mode.
4. Press to set date. Press to enter hour setting mode.
5. Press to set hour. Press to enter minute setting mode.
6. Press to set minute. Press to display current time.
7. Press once to display the date for a second.

LCD Display
Date & Time
Adjustable Band

Ultra
cool designs!

Choose a style that is all your own!

NOTE: Product is not water resistant. Do not immerse in water.

Note: Dispose of product after battery stops functioning. Product and colors may vary.

© 2002 Hasbro, Pawtucket, RI 02862 USA. All Rights Reserved. Distributed in the United Kingdom by Hasbro UK Ltd., Caswell Way, Newport, Gwent NP9 0YH. Distributed in Australia by Hasbro Australia Ltd., 570 Blaxland Road, Eastwood, NSW 2122, Australia. Tel: (02) 9874-0999. Distributed in New Zealand by Hasbro New Zealand Ltd., Albany Highways, Auckland, PO Box 100 940. North Shore Mail Centre, Auckland, New Zealand 1333. Tel: (649) 415-9916.

Hasbro Canada, Longueuil, QC, Canada J4G 1G2.

Please keep company details for future reference.

© denotes Reg. U.S. Pat. & TM Office

MADE IN CHINA. C-022E
Questions? Call 1-800-327-8264

TIGERTOYS.COM

for new products and offers

TIGER
ELECTRONICS



POWER
PAPER™

200205460BCT1-02

UPC PROOF OF PURCHASE

