

# PLAYTIME



### Dress up your baby doll to play all day, and later, get her ready for her bedtime!

### **BOTTLE TIME**



Before feeding your doll, make sure her diaper is fastened securely.



- 1. Fill bottle with clean, cold water or add clean, cold water and a packet of BABY ALIVE<sup>®</sup> Doll Juice Mix (sold separately).
- 2. Replace bottle top.
- 3. Hold doll in a reclining position. Make sure her head is higher than her tummy.
- 4. Place bottle tip securely in doll's mouth. Tip bottle up and give doll a few sips at a time.

# **Important Feeding Guidelines**

- Use only clean, cold water or BABY ALIVE® Doll Juice Mix (sold separately).
- Do not use real juice or other beverages.
- Do not use BABY ALIVE® Doll Food (sold separately); it is not designed for this doll.
- Do not feed doll more than one bottle of water or Doll Juice Mix (sold separately) between diaper changes.

# **DIAPER TIME**

After feeding your doll, you'll need to change her diaper!






- 1. Remove diaper and wipe doll clean with a soft, damp cloth or paper towel.
- 2. Put on a new diaper and fasten securely.
- ALWAYS change your doll's diaper and clean her after she drinks.
- **NEVER** let your doll sit with a wet diaper.
- Discard wet diapers; they cannot be washed or reused.

## **IMPORTANT CLEANING INSTRUCTIONS**

It is important to rinse doll clean immediately after each use. If using Doll Juice Mix and any juice remains in the doll, it can become difficult to clean.


- To clean doll after feeding her Doll Juice Mix, give her a bottle full of water until any remaining juice has been rinsed away and the water runs clear (it's best to do this over a sink).
- Use a soft cloth or paper towel to wipe away any juice on doll's mouth. Allow doll to dry.







- STAIN ADVISEMENT: Baby Alive® Doll Juice Mix (sold separately) may stain some surfaces. Adult supervision recommended. If spilled, wash with soap and water.
- Clean doll's face and body by wiping gently with a soft, damp cloth.
- Do not submerge doll in water; it is not intended for bath-time play.
- Do not place any foreign objects in doll's mouth or any other opening.
- Doll's clothes are machine washable (mild detergent, cold water, gentle cycle); they can also be spot-cleaned with a cool damp cloth; hang to dry.
- Hand-wash bottle with mild dish soap and water; it is not dishwasher-safe.



Product and colors may vary. © 2011 Hasbro. All Rights Reserved. TM & ® denote U.S. Trademarks. 36205 & 36206 PN 7167800000

