

PLAYSKOOL
believe in PLAY

Cherry Blossom MARKET

A PART OF THE DREAM TOWN™ COLLECTION

AGES

3+

Adult
assembly
required.

THANKS FOR PURCHASING THE
CHERRY BLOSSOM™ PRODUCE STAND.

PLEASE READ AND RETAIN THESE INSTRUCTIONS.

INCLUDES:

- 1 fabric Stand Cover
- 2 Side Brackets
- 3 Connector Rods


ALSO INCLUDES:

- 1 fabric strawberry, 1 fabric broccoli,
- 1 fabric ear of corn, 1 fabric pear,
- 1 fabric eggplant, 1 "recycle" fabric shopping bag.




ASSEMBLY:


- 1** Snap ends of one of the Rods into bottom clip of the Side Brackets as shown. Note position of Side Brackets tabs on End Frames.



- 2** Slide the other two rods into the fabric cover as shown.



- 3** Snap the ends of the rods in to the Side Brackets as shown. Be sure that the CHERRY BLOSSOM logo is positioned on the higher rod as shown.



- 4** Fasten the two fabric tabs on each side of the produce stand.

