

Littlest Pet Shop®

AGES 6+
66779 Asst.

PAWS ÖFF! ELECTRONIC DIARY

Thank you for purchasing
this Littlest Pet Shop®
product! Please read these
instructions thoroughly
and carefully.




x3 1.5VAA
R6 size
**BATTERIES
REQUIRED
NOT INCLUDED**

Alkaline batteries
recommended.
Phillips/cross head
screwdriver (not included)
needed to insert batteries.

TO INSERT BATTERIES

Using a Phillips/cross head screwdriver (not included), loosen screw in battery compartment cover (screw stays attached to cover). Insert 3 x 1.5V "AA" or R6 size batteries (not included). Replace cover and tighten screw.



CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
3. Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION


Please retain this information for future reference.

Batteries should be replaced by an adult.

CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Press the Reset Button if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.


GETTING TO KNOW YOUR DIARY



SETTING A PASSWORD

Your diary can only record a password that takes you a couple of seconds to say, so your password should be short (and easy to remember!). If you name the pet that comes with your diary, your pet's name can be your password!

Make sure it's quiet when you set your password! Any background noise may interfere with your setting your password.



1. Press the ON button.
2. Your diary will say, "Set your password."
3. Say your password, clearly and distinctly, into the microphone. You do not need to shout.
4. Your diary will say, "Repeat your password." Do so.
5. Your password is now saved. Your guard pet will make a happy sound, and the diary will pop open!

If you try to set a password and your diary cannot or did not recognize it, your guard pet will make an unhappy sound to let you know no password was set, and the diary will open. To try again, or to RESET your password use a paper clip to press the RESET button. Then follow the directions from the beginning.

OPENING THE DIARY

Press the ON button and wait for your diary to say, "Password, please." Say your password.

- If your diary recognizes the correct password, your guard pet will make a happy sound, and the diary will pop open.
- If you say the incorrect password – or you say nothing at all -- you have two more chances to try again. If the password is still incorrect, your guard pet will make an unhappy sound and the diary will not open!


TROUBLESHOOTING FOR OPENING THE DIARY

If the diary opens without asking "Password, please," this is a result of the password not being set properly. Press the RESET button and re-enter your password.


PSST!

This is a secret: if you forget your own password, press and hold the ON button for about 10 seconds and the door will pop open.

USING YOUR DIARY




Your diary comes with a pad of 20 sheets and stickers for decoration.



Press the button inside your diary, and your pet will interact with you.

When you are done using your diary, be sure the door clicks shut when you close it. And remember: don't tell anyone your password!

Remove your pet from the top of the diary and play with it! Just be sure to put it back, facing front, when you're done. This diary will only work with the pet that comes with it. (The pet does not need to be in place for diary features such as voice recognition to work.)



TROUBLESHOOTING

If the product begins acting erratically or freezes up, press the RESET button. Then follow directions from the beginning. If this measure does not work, replace the batteries with fresh batteries.

When batteries are running low, diary door may get locked in the open position. To close, press down on door while pressing ON button for 10 seconds.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

