

Littlest Pet Shop


AGES 4+
84310

Whirl Around Playground™


Thank you for purchasing this Littlest Pet Shop® toy! For maximum play value, please read and follow instructions carefully.

Playset includes 2 pets and accessories.


Pets and playset contain magnets. Other pets shown sold separately.




TO ASSEMBLE




Press elevator into place on side of playhouse.



Snap playhouse onto playset base, as shown.



Hook swing seats onto canopy.




Fit slide onto tree house, making sure it is also pressed into place on the base.


Adult Assembly Required.

! **WARNING:**
CHOKING HAZARD—Small parts.
Not for children under 3 years.


TO PLAY




Snap tree house onto base as shown.



Press canopy onto the tree house.




Press hammock into place between playhouse and tree house.



Press tunnel and flags into place on playset base.

Treetop swing set: Wind top clockwise, then place pet in the top seat (make sure print on pet's paw is touching paw print on seat) and let it go. Swings go 'round and 'round!

Turn top of the merry-go-round to make it spin!



Slide lever to race pet through the obstacle course!

© 2008 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.
84310 PN 6821750000

Visit



Littlestpetshop.com