


USER'S GUIDE


MiO
PUP™

THE FUTURE OF FRIENDSHIP™

 **x4 | BATTERIES INCLUDED**

Replace with 4 x 1.5V "AA" or LR6 size alkaline batteries. Phillips/cross head screwdriver (not included) needed to replace batteries.

AGES 6+



75044 Asst.


Thank you for purchasing MIO PUP™!

This MIO PUP pet walks, talks, moves, grooves, and glows. It's also a highly interactive companion!

When you talk to your new MIO PUP pet, it will “babble back” to you! Touch its sensors, and it will respond with movement, sound, and animation in its eyes!

To enjoy everything this MIO PUP pet can do – and everything you can do with it – please read these instructions carefully and thoroughly, and keep them for your reference.

GET TO KNOW YOUR MIO PUP™ PET



TURN YOUR MIO PUP™ PET ON AND OFF

When you take MIO PUP out of its package, MIO PUP will be in TRY-ME mode: slide the switch on its belly to the PLAY position and press the Nose Button.

MIO PUP is now in normal Play Mode.

When your MIO PUP pet senses no interaction after a few seconds, it will go into Hang-Out Mode and its eyes will reflect its current mood. For details about your MIO PUP pet's moods, see p. 6.


To turn your MIO PUP pet off, press and hold its Nose Button for about 3 seconds.

TALK TO YOUR MIO PUP™ PET

When you talk to your MIO PUP pet, it will “babble back” in its own language. It will also talk to you on its own, from time to time.

When you talk to your MIO PUP pet, you do not need to shout: only speak close to its microphone. MIO PUP may also respond to other sounds it hears, besides your voice.

Talk to your MIO PUP pet often! Its mood improves with interaction. For details about your MIO PUP pet's moods, see p. 6.




TOUCH YOUR MIO PUP™ PET

Just like a real pup, your MIO PUP pet loves to be held, touched, and played with!

Petting the Head

Stroking your MIO PUP pet's head calms it down, so do this whenever your MIO PUP pet is excited or angry (see p. 6-7). Lights on its head follow the direction of your petting. Your MIO PUP pet will make soothing sounds to calm you down, too! When your MIO PUP pet is relaxed, the “eye-con” of wavy lines appears in its eyes.



Tickling the Chin


Your MIO PUP pet loves to be tickled! Tickle your MIO PUP pet under its chin, and listen to it “laugh”! You will also see its mouth glow and its eyes show an “eye-con”.

Touch your MIO PUP pet often! Its mood improves with interaction. For details about your MIO PUP pet's moods, see p. 6.



'FEED' YOUR MIO PUP™ PET

Give MIO PUP its Feeding Bone anytime. MIO PUP will react differently, depending on whether or not it's hungry! You'll know MIO PUP is hungry by the bone-shaped "eye-con"! When you give MIO PUP its bone, don't take the bone away too soon, or MIO PUP will show a "sad" animation!




WALK YOUR MIO PUP™ PET

To make MIO PUP walk, tickle its chin 4 times in a row. (MIO PUP may walk on its own, too!) To stop MIO PUP walking, press the Nose Button. If you place and keep your hand on the Back Sensor of MIO PUP and then press the Nose Button twice, MIO PUP enters a "Secure Mode" in which MIO PUP does not walk. You can, however, still interact with MIO PUP. To release MIO PUP from this mode, place and keep your hand on the Back Sensor and then press the Nose Button twice.

HAVE YOUR MIO PUP™ PET PLAY MUSIC

Depending on your MIO PUP pet's mood, it will randomly play music designed to cheer you up, relax you, or get you on your feet. To activate these tunes, hold your MIO PUP pet's chin and tap its head sensor at the same time.



UNDERSTANDING YOUR MIO PUP PET'S MOODS/STATES

Your MIO PUP pet's mood is determined by how you interact with it and how often. Be sure to give your MIO PUP pet a variety of interaction!




LOVING

Your MIO PUP pet reaches this state when you put your hand on its back and pet it enough on the top of its head.




HAPPY

Your MIO PUP pet becomes HAPPY when it has received enough input and interaction with you.




EXCITED

When your MIO PUP pet is tickled too much, it will become EXCITED. Its eyes will display excited animations and its ears and tail will wag a lot. It may start walking around on its own! You may want to calm your MIO PUP pet down.




RELAXED

MIO PUP gets RELAXED when it has been pet a lot.




LONELY

If you don't talk to your MIO PUP pet on a regular basis, it could become LONELY. It could also become lonely if you routinely ignore it for long periods of time.




ANGRY

If you repeatedly tap your MIO PUP pet's Nose Button, it may become ANGRY.




SAD

If you do not pet your MIO PUP pet enough, it will become SAD. Play with and touch your MIO PUP pet to give it the attention and interaction it needs!




HUNGRY

When your MIO PUP pet has used up a lot of energy (for example, with talking and wagging), it needs to be "fed." Look for the BONE "eye-con" in its eyes and listen for barking to get your attention. Put the Feeding Bone in your MIO PUP pet's mouth and watch for an animation (a broken bone) in its eyes to let you know it's "feeding."




TIRED

When you first wake your MIO PUP pet up, it will be tired for a few minutes. Keep playing with it and it will wake right up. If you have been playing with your MIO PUP pet for a long time (approximately an hour), it will start to get tired and will need to take a nap. Leave your MIO PUP pet alone, and it will "go to sleep."



BORED

Your MIO PUP pet will get bored if you don't tickle it enough.



SICK

Your MIO PUP pet gets sick when it asks repeatedly to be "fed" and you don't give it its Feeding Bone. Your MIO PUP pet needs "feeding" and interaction to make it well again, but remember: the sicker your MIO PUP pet gets, the more attention, "feeding," and interaction it needs to become well again.




UNDERSTANDING "EYE-CONS"

Different "eye-cons" in your MIO PUP pet's eyes mean different states or moods. Reference the "eye-cons" below to see what your MIO PUP pet is feeling!

amused



babble



blink



carry



dizzy



ear tail wag



eating



eye



on switch



petting



scared



secure



song



sleep



thinking



tickle




walking



TO REPLACE BATTERIES

Use a Phillips/cross head screwdriver (not included) to loosen screw in the battery compartment doors (screw remains attached to door). Remove the doors and replace with 4 x 1.5V "AA" or LR6 size alkaline batteries (not included). Replace doors and tighten screws.



CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
2. Do not mix old batteries and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
3. Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference.

Batteries should be replaced by an adult.




CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and – polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**

TROUBLESHOOTING

If this product freezes up or acts erratically, change the batteries or press the Reset Button with the tip of a pen. Doing so will reset the product's "mood" state.




FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

More than
100
'eye-cons'
reveal my many
feelings!



© 2007 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.
75044 Asst. PN 6732360000

Product and colors may vary.

VISIT

TIGERELECTRONICS.com

Questions? Call 1-800-844-3733