




To get the best performance from your FURYFIRE blaster, be sure to read the instruction booklet. Here are some additional tips:



When loading darts into the Launching Tubes:

- Always insert darts fully into tubes; press darts in so no part of the dart tip is exposed.



When firing the blaster:

- Be sure to pull Spring-Loaded Slide all the way back (until it clicks) and all the way forward before pulling trigger.



- If you pump the Spring-Loaded Slide too quickly after firing, darts may get jammed in the barrel. Make sure cartridge finishes rotating after your shot before pumping Spring-Loaded Slide again.



© 2009 Hasbro. All Rights Reserved.
TM & © denote U.S. Trademarks.
U.S. Pat. Nos. 5529050, 7287526 and patent pending.
92764/926950900 Asst. PN 6962770000

Questions? Call 1-800-327-8264

