

AGES 8+

**INSTANT ONLINE
GAME SYSTEM**



NET

JET™

**NETJET™ KEY
INSTALLATION**


CONTENTS

1 Key


SET UP AND GAME PLAY

NOTE: You will need the NET JET game controller (sold separately) in order to use this Key.

1. Power up your PC and connect to the Internet.
2. Insert the USB connector into your computer's USB port.



3. Insert your NET JET Key into the controller (sold separately). The blue circle on the controller will light up when the key is inserted correctly.



4. You should instantly launch into the NET JET game system where you will receive onscreen instructions. Follow the instructions as they guide you through setup and play. If this does not happen, refer to the troubleshooting section of these instructions.

NOTE:

When you connect to the NET JET Instant Online Game System, you should automatically download and install the necessary software programs from our secure server to run NET JET games. This is not a website and you cannot navigate out of it.

GAME CONTROLS

The controls on your NET JET controller will vary by game. Please follow the online instructions for each individual game.

AFTER INITIAL INSTALLATION

1. Once installed, you'll have a NET JET icon on your desktop. Double click on this icon to reconnect. (NET JET controller must be plugged into the USB port)
2. Changing keys - To use other NET JET keys, remove key from the controller and insert the new key. Follow the online instructions to start new game.

CONNECTING

Although the system will function with a standard dial-up connection, for optimal results, we recommend using a high-speed Internet connection with the NET JET Instant Online Game System.

NOTE:

You will remain connected to the internet throughout gameplay.

TROUBLESHOOTING

If you are experiencing a problem not listed here, please check the Frequently Asked Questions section at netjetgames.com. If your question is not answered there, please contact Hasbro Consumer Affairs at the phone number or address below.

Before you plug the Controller in for the first time, please ensure that your computer is turned on and is ready to use. If you have not disabled your firewall or anti-spyware programs, you may be prompted to approve the connection to the Internet and/or download data. Follow the instructions as you are prompted, otherwise the installation process may not be complete.

While you are installing the game system, try not to let your computer shut down or go into Sleep mode. Be sure your Internet connection does not drop and **your controller remains plugged in at all times.** If any of these situations occurs during installation, unplug the Controller, re-boot the computer, **connect to the Internet, then plug the Controller back in.**

Finally, in your My Computer folder on your desktop you will notice a NET JET icon that looks and acts like a CD-ROM. Please note that this is not a CD-ROM device, but contains necessary components of the NET JET game system. Please do not attempt to "play" the apparent CD-ROM called "NET JET" as this could cause damage to the files that have been installed.

FIREWALL WARNING - If you cannot connect to the Internet, please check to ensure that your Firewall program allows NET JET to connect to the Internet to download and upload data.

SPYWARE WARNING - If you cannot connect to the Internet, please turn off any anti-spyware application you may have running and then restart the computer.

BROWSER ERRORS - If you encounter other problems with connecting to the Internet, please turn off and restart your Internet browser program.

CONSUMER INFORMATION

We will be happy to hear your questions or comments about this game. US consumers please write to: Hasbro Games, Consumer Affairs Dept., P.O. Box 200, Pawtucket, RI 02862 or telephone 888-836-7025 (toll free). Canadian consumers please write to: Hasbro Canada Corporation, 2350 de la Province, Longueuil, QC Canada, J4G 1G2. European consumers please write to: Hasbro UK Ltd., Hasbro Consumer Affairs, P.O. BOX 43, Caswell Way, Newport, Wales, NP194YD, or telephone our Helpline on 00 800 2242 7276.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TU technician for help.

Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.

If you have any questions, please contact:

Consumer Affairs Hasbro Inc.

1027 Newport Avenue,

Pawtucket, RI

Tel: 1-800-844-3733

Fax: 1-401-431-8082