

ASSEMBLY


1 Attach Cake Stamping Station.




2 Attach Frosting Station.



3 Attach display case.



4 Insert extruder, cake stand, and accessories.



Cleaning: Remove the excess compound from the tools and accessories. You can use the included plastic knife to scrape away compound. Allow the remaining compound to dry, then scrape or vacuum it away.

Note: Always put compound back in container after play.

Questions? Call: 1-800-327-8264 Product and colors will vary.
PLAY-DOH and the PLAY-DOH logo are trademarks identifying quality modeling compound products produced exclusively by Hasbro, Inc.
© 2012 Hasbro. All Rights Reserved. TM & © denote U.S. Trademarks.
U.S. Patent No. 6713624 and U.S. Patent Pending.
A0318 PN 7314730000



Frosting Fun Bakery™

AGES
3+



To see a video demonstration of this playset, visit Play-Doh.com!

Fun to play with, but not to eat. Adult assembly required.

NOTICE TO PARENTS:
CONTAINS WHEAT. CONFORMS TO ASTM D-4236. NONTOXIC.

CONTENTS: Playset, 2-piece extruder, shelf, tray, cake stand, turntable, display dome, 4 cake cutters, 4 extruder tips, cupcake liner, cake server, plate, plastic knife, fork, 2 cans of PLAY-DOH Brand Modeling Compound and 2 cans of PLAY-DOH PLUS compound.


SEE BACK PANEL FOR ASSEMBLY INSTRUCTIONS.



CAKE STAMPING STATION

Classic PLAY-DOH Compound Recommended.


1. Attach cake cutter!



Choose a cake cutter shape and snap it into stamping station.



- Place flattened compound onto turntable.
- Place turntable onto cake stamping station.



Press down. You have created a PLAY-DOH cake layer!

Now, move your turntable to the Frosting Station to decorate your "cake"!

INTRODUCING

PLAY-DOH® PLUS!

What's the difference?



Classic PLAY-DOH Compound:

- Best for rolling, cutting and shaping in molds.
- Make a pretend cake!
- Mold fun shapes!
- Use in Cake Stamping Station.

PLAY-DOH PLUS Compound:

- Best for placing in extruders to press out compound.
- Add "frosting" details!
- Press out pretend frosting!
- Use in Frosting Station.

Use turntable to move your "cake" from the Cake Stamping Station to the Frosting Station.




FROSTING STATION

PLAY-DOH PLUS Compound Recommended.


1. Choose a "frosting" tip!




Remove extruder from center of Frosting Station.



Twist off current tip from extruder, and tighten.



Place extruder back into Frosting Station.




Troubleshooting: Make sure the tip is tightened; otherwise tip will pop off during play.

2. Press PLAY-DOH PLUS frosting!

1. Remove plunger and place PLAY-DOH PLUS compound into extruder.

2. Place turntable in center slot to "frost" the middle of your pretend cake OR place in the side slot to "frost" the edges.



Hint: You can also keep the extruder out to decorate by hand!



3. Re-insert and press down on plunger to add PLAY-DOH PLUS frosting dollops to your PLAY-DOH cake!

Add fun shapes with classic PLAY-DOH!

Display your creations on the cake stand!

Fill cupcake liner and decorate with PLAY-DOH PLUS!

