


ages &  
stages®

3+  
years

Thank you for choosing this  
PLAYSKOOL toy!



**Adult assembly required.**

Phillips/cross head  
screwdriver (not included)  
needed for assembly.

  
kid  
motion™

easy dunk  
basketball™

**PLAYSKOOL**



believe in PLAY!™

05332

# assembly instructions


1

Snap hoop (A)  
onto clamp (B) on  
front plate.




2

Snap stabilizer (D) up into back plate (C).



3

Place on doorknob/handle.





Not suitable for children under 3 years  
because of small parts/choking hazard.



Product and colors may vary.  
© 2007 Hasbro. All Rights Reserved.  
TM & ® denote U.S. Trademarks.  
Patent Pending.  
05332 PN 6735760000



Questions? Call 1-800-PLAYSKL