

# SPIDER-MAN 3

## VENOM'S Vengeance Chopper

**AGES 4+**  
69220/69129 Asst.




### CAUTION:

Hair entanglement may result if child's hair comes in contact with moving parts of toy. Adult supervision is required.


**1**

Lock bike into launcher.




**2**

Insert ripcord with teeth facing up.




**3**

Holding the launcher and bike near the floor, tilt the launcher back so that the front wheel of the bike is slightly elevated.




**4**

Quickly pull the cord out of the bike. The bike can be launched without the launcher too!




**5**

Lower both wheels of the bike to the floor.



**6**

The bike will launch and race away!



For better performance:  
Give the launcher a slight push forward as you launch!



**SPIDER-MAN**  
MERCHANDISING

**COLUMBIA PICTURES**

© 2006 COLUMBIA PICTURES INDUSTRIES, INC. ALL RIGHTS RESERVED.



Not suitable for children under 3 years because of small parts — choking hazard.

Spider-Man and all related characters and the distinctive likeness thereof: TM & © 2007 Marvel Characters, Inc. Spider-Man 3, the Movie: TM & © 2007 Columbia Pictures Industries, Inc. All rights reserved.

[www.marvel.com](http://www.marvel.com)

®\* and/or TM\* & © 2007 Hasbro. All Rights Reserved.

TM & ® denote U.S. Trademarks.

**P/N: 6690050000**