

MARVEL, Spider-Man & Friends and all related characters and the distinctive likeness thereof are trademark of Marvel Characters, Inc., and are used with permission. Copyright © 2007 Marvel Characters, Inc. All rights reserved. www.marvel.com. Produced under license from Marvel Characters, Inc.

 $\mathbb{B}^*$  and/or TM\* and  $\mathbb{O}$  2007 Hasbro. All Rights Reserved. TM &  $\mathbb{B}$  denote U.S. trademarks.

P/N: 6737750000





Adventure will and water and THE HULK on land and water LITTLE ADVENTURE WATER RESCUE! Now you can join SPIDER-MAN and his friends for adventure on the high seas! Please read and retain these instructions before playing with this toy.



PLAYSKOOL


Untile Adventure


## Turn wheel to retract rope.

## Press here to squirt water.

\* This feature will only work if the boat is floating in water. It may take 2-3 presses of the button before water squirts from the cannon.

Clip the rescue rope around figures.





Pull clip to extend rope.

When finished playing: Remove toy from water and allow to dry.