

Use Cool Gears and Shapes to Create Fun Designs and Pictures!

Now Try These!

You can make an endless number of SPIROGRAPH creations! For your own unique designs, place a marker (not included) in any of the numbered gear holes and start drawing! For more detailed designs, you can alternate the gear holes you use, and even add different gears to the same design. Then, turn your designs into pictures using the drawing template. Draw everything from insects to spaceships! It's fun, easy and so creative!

Butterfly

Gear Template: Circle
Gear: 22
Gear Hole: 1

Flower

Gear Template: Circle
Gear: 27
Gear Hole: 1

Flower

Gear Template: Circle
Gear: 30
Gear Hole: 4

Galaxy

Gear Template: Ellipse
Gear: 33
Gear Hole: 5

Planets

Gear Template: Circle
Gear: 18
Gear Hole: 1

Hair

Gear Template: Circle
Gear: 30
Gear Hole: 10

Mouth

Gear Template: Circle
Gear: 29
Gear Hole: 6

Lobster

Gear Template: Circle
Gear: 22
Gear Hole: 4

Crab

Gear Template: Circle
Gear: 18
Gear Hole: 1

Turtle

Gear Template: Ellipse
Gear: 30
Gear Hole: 6



WARNING:

CHOKING HAZARD-Small parts.
Not for children under 3 years.

AGES 5+



Deluxe Spirograph[®] Design Guide

Includes tray with built-in storage, 7 gears,
gear template, drawing template and paper.



Not suitable for children
under 3 years because of
small parts — choking hazard.



32594

Know the Basics

Create a SPIROGRAPH Design!

1. Place the gear template (SPIROGRAPH logo facing up) on a sheet of paper inside the tray.
2. Select a gear and place it in one of the gear template openings (circle, oval, kidney) so that the teeth on the gear and opening are engaged.
3. Put the tip of a marker (not included) into one of the gear holes, and move the tip around the inside of the opening. *Always keep the teeth on the gear and opening engaged as you draw!* Draw around the opening until the line returns to the point where you started.

Draw a Picture!

Place the drawing template on a sheet of paper. Then, use a marker (not included) to trace around the inside of one of the shapes. Combine different shapes for a complete picture!

Store the Gears!

On the SPIROGRAPH tray, you'll find areas for gear and marker storage. The gear slots are sized to fit each of the seven gears.

HASBRO.COM
FOR NEW PRODUCTS AND OFFERS

Questions? Call: 1-800-327-8264

Stain Advisement: Note that marker may stain some surfaces. Adult supervision is recommended. Wash with soap and warm water.

CONFORMS TO ASTM D-4236


Product and colors may vary.
© 2010 Hasbro. All Rights Reserved.
TM and ® denote U.S. Trademarks.



Marker not included.

Step 1

Create a SPIROGRAPH design using:
GEAR TEMPLATE: CIRCLE
GEAR: 18
GEAR HOLE: 1




WOW!!
It's a
Crab!

Step 2

Place the drawing
template over your
SPIROGRAPH design
and trace eyes,
claws and legs.



Combine
Your
Designs
and
Shapes!



Step 3

Use crayons,
markers or colored pencils
(not included) to color in
your new creation.

P/N 7106570000