FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.
 WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Alkaline batteries recommended. Phillips/cross head screwdriver (not included) needed to insert batteries.





ULTIMATE LIGHTSABER

BUILD YOUR OWN LIGHTSABER



The Clone Wars are raging across the galaxy. Join the fight and wield the chosen weapon of the Jedi and the Sith: the lightsaber.

Complete your training by constructing this mystical weapon and reveal which side of the Force you choose in this epic struggle. Construct authentic lightsaber designs or create your own unique designs as often as you wish.

The power of the Force is in your hands!



Not suitable for children under 3 years because of small parts - choking hazard.




Product and colors may vary.


© 2008 Lucasfilm Ltd. & ® or TM where indicated. All rights reserved.

®* and/or TM* & © 2007 Hasbro. All Rights Reserved.

TM & ® denote U.S. Trademarks.

P/N 6769590000







CAUTION: TO AVOID BATTERY LEAKAGE

- 1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- 2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- 3. Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.




CAUTION:

- Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
- Do not mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
- 3. Remove exhausted or dead batteries from the product.
- 4. Remove batteries if product is not to be played with for a long time.
- 5. Do not short-circuit the supply terminals.
- Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
- RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.

III STEP 2

Install one or more crystals into the chamber in the hilt.




Each crystal causes the lightsaber to emit a different sound. After you complete your lightsaber, you can always switch, add or remove crystals.


Color Chart:
Red: red crystal
Blue: blue crystal
Green: green crystal
Aqua: blue and green crystals
Orange: red and green crystals
Purple: red and blue crystals


Note: If the crystals become misplaced or lost, turn the power on and off (see "Power Up" section below) to cycle through the different blade colors and sounds.

Store the extra crystals in the storage chamber.











I I FINISHED

Congratulations! You have assembled your lightsaber!


CUSTOMIZE III

The above steps are the basic steps for building a lightsaber. Switch and combine the parts to customize your lightsaber!

NOTE: Some configurations will cover the power button. Please be sure that the power button is exposed when completing your configuration.

III POWER UP

Practice your dueling skills! Press the button to "power up" your lightsaber.



When customizing your lightsaber, always make sure the button is exposed so that you can "power up"!

