



Ages 4 and Up


27644/26142

TIE FIGHTER


ASSEMBLY REQUIRED. NO TOOLS NEEDED.

ASSEMBLY:

Attach wings to fighter.




SEAT:




Seat is removable. Grasp seat and pull up and forward while moving the seat back and forth. To replace seat, press it back in place.

OPERATION:

To eject wings, press button on each wing pylon.



CANNONS:



Manually pull cannons to extend for battle.



Product and colors may vary.
© 2010 Lucasfilm Ltd. & © or TM where indicated. All rights reserved.
®* and/or TM* & © 2010 Hasbro. All Rights Reserved.
TM & © denote U.S. Trademarks. PN: 7079810000



Not suitable for children under 3 years because of small parts — choking hazard.