

AGES 4+


Strawberry
Shortcake™

WARNING:

CHOKING HAZARD-Small parts.
Not for children under 3 years.

Berry Sparkling Charms™



Includes:



x2
1.5V AAA or R03 size
**BATTERIES
INCLUDED**

Replace with 2 x 1.5V "AAA"
or R03 size batteries.
Alkaline batteries recommended.
Phillips/cross head screwdriver
(not included) needed to
replace batteries.


TO PLAY



NOTE: Remove doll's shoes before placing doll inside the Berry Sparkling Charms™ dress.




Press charms into the flowers on the Berry Sparkling Charms™ dress.



Press to light-up charms!


4

Place remaining charms on headband. Headband can be worn as a bracelet for you!



TO REPLACE BATTERIES

1. Turn Berry Sparkling Charms™ dress upside down.
2. Use a Phillips/cross head screwdriver (not included) to loosen screw in battery compartment cover (screw remains attached to cover).
3. Remove cover. Remove and discard old batteries. Replace with 2 x 1.5V "AAA" or R03 size batteries. Alkaline batteries recommended.
4. Replace cover and tighten screw.



IMPORTANT: BATTERY INFORMATION



CAUTION:

1. As with all small batteries, the batteries used with this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect. If you reside outside the United States, have the doctor call your local poison control center.
2. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and – polarity markings.
3. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
4. Remove exhausted or dead batteries from the product.
5. Remove batteries if product is not to be played with for a long time.
6. Do not short-circuit the supply terminals.
7. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
8. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**



Strawberry Shortcake™ and related trademarks © 2011 Those Characters From Cleveland, Inc. Used under license by Hasbro, Inc. American Greetings with rose logo is a trademark of AGC, LLC.

®* and/or TM* & © 2011 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.

32401

PN 7188550000

Product and colors may vary.

