

Hair entanglement may result if child's hair comes in contact with moving parts of toy. Adult supervision is required.

Twirling Flower Fashions™

Your Strawberry Shortcake doll comes with 2 color-change skirts, I fashion maker base, doll stand, flower spritzer, stem and a splashguard.

(Strawberry)

TO PLAY




Remove doll's skirt. Remove plastic shrink-wrap and discard. Reattach skirt with white side facing out.



Place strawberry shortcake doll on the base. Make sure to fit holes on both feet over the posts at the center of the yellow flower spinner.

Ask a grown-up for help filling the flower spritzer. Squeeze it and release it underwater.







Once the flower spritzer is full of water, attach stem to the base.

NOTE: Doll stand is not required for operation.

How to create water designs on your doll's skirts:

slide the lever at the front of the base until it is positioned all the way to the right. Secure lever by pushing it up slightly.



Push down slightly on the lever to activate the spinning motion.

As the doll is spinning, press the flower spritzer to squirt water on the colorchange skirt and watch designs "magically" appear! Remember, you can always detach the flower spritzer to squirt water exactly where you want it.



Allow the skirt to dry completely and create a unique design all over again.

Water will accumulate in the base. Make sure to empty after each use to prevent overflowing.

IMPORTANT: Do not use cleaning solutions on Strawberry Shortcake's skirts.

NOTE: Results will vary every time.





Product and colors may vary.

Strawberry Shortcake™ and related trademarks © 2010 Those Characters From Cleveland, Inc. Used under license by Hasbro, Inc. American Greetings with rose logo is a trademark of AGC, LLC.

 ${\ensuremath{\mathbb R}}^*$ and/or TM* & ${\ensuremath{\mathbb C}}$ 2010 Hasbro. All Rights Reserved. TM & ${\ensuremath{\mathbb R}}$ denote U.S. Trademarks.



28855 PN 7127310000

Questions? Call 1-800-327-8264