

# TRANSFORMERS GENERATIONS FORMERS



GRIMLOCK®  
FALL OF CYBERTRON™

AGES 5+  
A1602/A1403 ASST.







X2 A76 ALKALINE BATTERIES INCLUDED


LEVEL: 0 1 2 3  
INTERMEDIATE

NOTE: Some parts are made to detach if excessive force is applied, and are designed to be reattached if separation occurs. Adult supervision may be necessary for younger children.




## CHANGING TO DINOSAUR





**TO REPLACE BATTERIES**

Phillips/cross head screwdriver (not included) needed to insert batteries. Loosen screw in battery compartment cover (screw remains attached to cover). Remove cover. Remove and discard batteries. Replace with 2 x 1.5V A76 alkaline batteries. Replace cover and tighten screw.



**IMPORTANT: BATTERY INFORMATION**

**! CAUTION:**

1. As with all small batteries, the batteries used with this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect. If you reside outside the United States, have the doctor call your local poison control center.
2. **TO AVOID BATTERY LEAKAGE**
  - a. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
  - b. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
  - c. Remove exhausted or dead batteries from the product.
  - d. Remove batteries if product is not to be played with for a long time.
  - e. Do not short-circuit the supply terminals.
  - f. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**
3. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.



Retain instructions for future reference.

Product and colors may vary. Some poses may require additional support. Manufactured under license from TOMY Company, Ltd. © 2012 Hasbro. All Rights Reserved. TM & © denote U.S. Trademarks.

P/N 7326790000

[TRANSFORMERS.COM/INSTRUCTIONS](http://TRANSFORMERS.COM/INSTRUCTIONS)