


TRANSFORMERS PRIME

ENERGON DRILLER™
WITH **KNOCK OUT®**



WARNING:

CHOKING HAZARD—Small parts.
Not for children under 3 years.

AGES 5+


38002/38003 ASST.

x2 1.5VAAA
ALKALINE BATTERIES REQUIRED
DEMO BATTERIES INCLUDED







EASY LEVEL
1 2 3


NOTE: Some parts are made to detach if excessive force is applied, and are designed to be reattached if separation occurs. Adult supervision may be necessary for younger children.

MODE 1





MODE 2





TO REPLACE BATTERIES

Replace demo batteries with alkaline batteries. Phillips/cross head screwdriver (not included) needed to insert batteries. Loosen screw in battery compartment cover (screw remains attached to cover). Remove cover. Remove and discard demo batteries. Replace with 2 x 1.5V AAA alkaline batteries. Replace cover and tighten screw.



IMPORTANT: BATTERY INFORMATION



CAUTION:

1. As with all small batteries, the batteries used with this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect. If you reside outside the United States, have the doctor call your local poison control center.
2. TO AVOID BATTERY LEAKAGE
 - a. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
 - b. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
 - c. Remove exhausted or dead batteries from the product.
 - d. Remove batteries if product is not to be played with for a long time.
 - e. Do not short-circuit the supply terminals.
 - f. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.
3. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.

Retain instructions for future reference.

Product and colors may vary. Some poses may require additional support. Manufactured under license from TOMY Company, Ltd. © 2011 Hasbro. All Rights Reserved. TM & © denote U.S. Trademarks.

P/N 7246940000

TRANSFORMERS.COM/INSTRUCTIONS