


AGES 3+

CRAVITY EOTS

If figure is stuck between modes, or not converting properly:

- 1. Set figure on feet.
- 2. Rotate and press arms, torso, and head so that figure is in robot mode. There may be a clicking sound.
- 3. Place figure on wheels. It should convert to vehicle mode.
- 4. Repeat this process until conversion works properly.

Product and colors may vary.



P/N 6998990000

TRANSFORMERS.COM







© 2009 DreamWorks LLC and Paramount Pictures Corporation © 2009 Hasbro. All Rights Reserved.

TM & ® denote U.S. Trademarks.

Manufactured under license from Tomy Company, Ltd.



Not suitable for children under 3 years because of small parts - choking hazard.