



Crime Stalker™

INSTRUCTIONS

Vehicle




BATMAN and all related elements are the property of DC Comics. TM and © 1994 All Rights Reserved.


© Kenner Products, A Division of Tonka Corporation, Cincinnati, Ohio 45202

1 ONE-TIME ASSEMBLY
Once assembled, cannot be taken apart!


Attach both wheel covers.




2 Attach ground level blaster.




3 Insert right wing at an angle, starting at the front of the wing, then inserting the back.




4 Insert left wing at an angle, starting at the front of the wing, then inserting the back.






5 Insert the top wing at an angle, starting at the front of the vehicle.




6 Load turbo missile.




7 Apply labels following numbers on label sheet using this illustration as a guide.




- 8** Remove battery shipping protector tab.




- 9** Place figure into vehicle. Fits most Batman® figures from the Animated Series Collection.




- 10** The engine has two sound positions:
1. Raise it all the way up and hold it and you hear a "laser" sound.
2. Release the engine and it settles slightly and you hear the engine sound.



- 11** While the engine is in the up position, rotate the exhaust pipe to raise the side mounted weapon and to hear "laser blast" sound.



- 12** Turbo missile can be fired only when engine is in up position by pressing firing button on side of the engine.



- 13** To change batteries have an adult remove screw and battery compartment door. Replace with two A76 batteries. Screw compartment door back into place.

