




64158

AGES 4 AND UP


BATMAN FOREVER ELECTRONIC BATMOBILE® VEHICLE

INSTRUCTIONS

1 Apply labels using the numbers on label sheet and these illustrations as a guide.




4 Place wherever you choose.




After applying label to cockpit, attach the canopy as shown.


2 Snap wheel covers onto all four wheels.




3 Nest the two tail fins together as shown. Fins should be exactly lined up as shown.



4 Holding the two fins together, insert the front end into the slot first. Then rotate the back down, snapping them into place.



5 The tail fin can be manually opened and closed.




*© and © 1995 TONKA CORPORATION, a subsidiary of Hasbro, Inc., Pawtucket, Rhode Island 02862. All Rights Reserved.


BATMAN and all related elements are the property of DC Comics. TM and © 1995. All Rights Reserved.

51941300
MADE IN MEXICO

- 6** Attach each fender fin by snapping both C-clamps onto rod in fender, then rotate fin down into place as shown. The fins can be rotated up for pretend firing.




- 7** Load missile into front of vehicle. To fire missile, push button on hood.



- 8** Unscrew panels and remove compartment cover. Install 2 "C" alkaline batteries. If the bulb burns out, remove bulb and replace with PR-2 bulb.

CAUTION: To avoid battery leakage, (1) Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instructions. (2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable batteries. (3) Always remove exhausted or dead batteries from the product.



- 9** Press light button at back of vehicle to turn on lights. The light is on only when the button is depressed.

