

NERF®




AGES 6+

**N-STRIKE®
LONGSTRIKE CS-6™**

Be sure to read and follow all instructions carefully before using this product.

! **CAUTION:** Do not aim at eyes or face.


TO AVOID INJURY: Use only darts designed for this product.
Do not modify darts or dart blasters.




*Additional clips sold separately.

NOTE: Accessories from other N-STRIKE® blasters will work with the tactical rails!

ASSEMBLY




1. Insert bolt into mechanism and plug on other end of bolt.*




2. Attach shoulder stock.*


* These parts cannot be removed once they are attached.



3. Slide flip-up sight onto tactical rail until it locks.




4. Attach barrel extension by sliding into place...



5. ...and twisting 90 degrees to lock.


LOADING AMMO




Load darts into Quick-Reload Clip.

- Insert 1 CLIP-SYSTEM DART at a time and push down.
- Be sure darts are inserted in direction indicated on clip.
- Clip can hold up to 6 CLIP-SYSTEM DARTS.


INSERTING CLIP



- 1.** Pull cocking mechanism all the way back until fire-ready indicator is red.




- 2.** Insert clip.




- 3.** Slide cocking mechanism all the way forward to load 1 dart in the chamber.

FIRING



1. With cocking mechanism fully forward, pull trigger to fire 1 dart.




2. To fire again:

- Slide cocking mechanism all the way back and all the way forward to load another dart.
- Pull trigger to fire.
- Repeat this step until clip is empty.

NOTE: Be sure to slide cocking mechanism all the way back and all the way forward before pulling trigger. If mechanism seems locked up, pull it all the way back to reset, then all the way forward.

RELOADING




- 1.** Before removing clip from blaster, pull cocking mechanism all the way back.
- 2.** Press **clip release button** to remove clip.
- 3.** Repeat steps for loading ammo.


USING THE SIGHTS

Using the built-in iron sights and the attachable flip-up sight, there are several ways you can aim at your target. See which one works best for you and your targeting situation:


NOTE: Options 2–5 are with flip-up sight attached (see Assembly section).




1. If flip-up sight is not attached, line up rear iron sight to front iron sight and acquire target.




2. Line up grooves with tube and acquire target.



3. Line up center of hole with ridge above tube and acquire target.




4. Line up center of hole with center pin and acquire target.




5. For long-range targeting, line up hash marks on forward flip-up sight with top of front iron sight and acquire target. If the target is farther away, use the higher hash marks.


CLEARING A JAM




1. If cocking mechanism seems stuck, try pulling the trigger first.



2. Pull cocking mechanism back and press clip release button to remove clip. Check for a jammed dart in the clip area.



3. Open the jam clearing door and remove the jammed dart. Close door.



4. Replace clip and slide cocking mechanism forward. This should load another dart.



Product and colors may vary.
© 2009 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.
U.S. Pat. Nos. 5529050, 7287526 and Patent Pending.
60623/605820900 Asst. PN **6970330000**



Not suitable for children under 3 years because of small parts - choking hazard.

