

FLASH FLOODTH Instructions

Body Target Instructions









Place end of hose/faucet into Quick Fill Cap. Press down and fill with clean, clear water. Pump 30 to 35 times to pressurize.

Pull trigger to blast out streams of water.

Pull back FLASH FLOOD trigger for a drenching blast of water.



Remove Body Target paper backing and dispose of properly.

Stick adhesive side of Body Target onto your body and blast away!

IMPORTANT: SUPER SOAKER SOAKERTAG ELITE Body Targets have been thoroughly tested. However, as with cosmetics, some individuals may experience minor irritation. If irritation occurs, rinse with water and discontinue use.