



Contains: Left and right Copter body, ripcord, left and right launcher halves, main shaft, launcher activation shaft, rotor, 2 launcher connecting rings, 2 body connecting rings, retaining clip, "ACE"™ figure, label sheet, blueprints and instructions.

MAIN SHAFT ASSEMBLY



BODY ASSEMBLY



ROTOR INSERTION







FIGURE CLIP INSERTION




LAUNCHER ACTIVATION SHAFT ASSEMBLY




CONNECTING RINGS APPLICATION



RIPCORD AND FIGURE INSTALLATION



LAUNCHING THE BATTLE COPTER




- 1 Fit main shaft onto grooved area in body half with rudder as shown. (ILL. 1)
- 2 Fit second body half onto body half with rudder then snap connecting rings onto assembled body top and bottom as shown. (ILL. 2)
- 3 Snap rotor over main shaft as shown. (ILL. 3)
- 4 Fit figure retaining clip into hole in body. (ILL. 4)
- 5 Fit launcher activation shaft over grooved area on launcher handle half as shown. Fit other launcher handle half over shaft and handle. (ILL. 5)
- 6 Snap top connecting ring (with grooves) over top end of launcher handle as shown. Snap bottom connecting ring onto bottom of launcher handle. (ILL. 6)
- 7 Insert ripcord into slot with molded arrow above it AS SHOWN. (INSET) Make sure ripcord grooves are facing toward middle of handle when inserting. First snap figure into retaining clip, then attach hands to handles. NOTE: RIPCORD **MUST** BE INSERTED CORRECTLY INTO SLOT FOR BATTLE COPTER TO OPERATE PROPERLY! (ILL. 7)
- 8 Align rib in copter with notch on handle and fit together. Grasp handle, then in a quick, smooth motion, pull the ripcord and the Battle Copter will fly off the handle. (NOTE: Be sure copter flies away from face and eyes.) (ILL. 8)


G.I. JOE® BATTLE COPTER™

OFFICIAL G.I. JOE VEHICLE SPECIFICATIONS

- 1) EASY-GRIP, HIGH STRESS RIPCORD
- 2) AERODYNAMIC, CIRCULAR REVOLUTION FLIGHT ROTOR
- 3) PERSONNEL SECURITY BRACE FOR HIGH-ALTITUDE MANEUVERS
- 4) IMPACT-PROOF, FULL-THROTTLE POWER PLANT/LAUNCHER
- 5) LIGHTWEIGHT, FLEXI-STRUCTURE SHAFT
- 6) REAR MOBILITY, DIRECTIONAL BALANCE RUDDER STABILIZER



Peel and apply labels as shown.



PLACE LABEL ON OTHER
SIDE OF STABILIZER RUDDER