



# My First In-Line Skates™

Ages 3-6

50017 Asst.

Please read entire instructions before allowing child to skate.

Tool needed: flathead screwdriver to adjust wheel settings.

Includes: Two fully assembled skates.

(Children should wear socks that fit above the "high-top" ankle support boot when skating.)


**ADJUSTING STAGES** In-Line Skates feature three easy-to-learn skating stages.

**STAGE 1:** Beginners use the training wheel setting with wheels locked in the "forward only rolling" position. This provides them with a wider base for maximum stability.


**STAGE 2:** Training wheels can then be slid "in-line" while keeping wheels locked with "forward only rolling."

**STAGE 3:** Wheels can be unlocked for free-wheeling, "in-line" fun for confident skaters.

## TRAINING WHEEL POSITION




1. Push training wheel button toward back of skate and hold in place.



2. Slide training wheel (middle wheel) all the way out, then release training wheel button to lock wheel in place. Push in on wheel to make sure it is locked. Repeat process to slide wheel back to the "in-line" position.

## LOCKED WHEEL POSITION




1. To lock wheels in the "forward only" rolling position, turn the locking switch to the "ON" position. Wheels will not roll backwards in this setting. **NOTE:** For easier positioning, a flathead screwdriver can help with turning the locking switch.
2. To return wheels to the "free wheeling" mode, turn the locking switch to the "OFF" position. Wheels will roll both forwards and backwards in this setting.

## SAFETY CAUTIONS:


- Always supervise novice skaters since a few falls are unavoidable. To best assist a beginner, hold one of their hands and guide them along a smooth, level surface.
- Children should always use helmets, wrist guards, kneepads, and elbow pads to help guard against injury.
- Sneakers (or shoes) and socks must be worn while wearing the skates. Don't let child skate in bare feet, thongs, sandals or any other open-toed shoes.
- Check to prevent pant legs, loose laces, etc. from becoming caught in wheels.
- Select skating areas which are free from obstacles and provide a flat skating surface.
- Never let child skate in the street.
- Never let child skate in driveways which enter vehicle traffic routes.
- Never tow skaters with a bicycle or a car.

## FITTING IN-LINE SKATES


Playskool In-Line Skates are designed to fit children's shoe sizes 6-12. They can be adjusted to fit your child's sneaker or shoe as follows:




1. Press in the adjustment buttons located on sides of skates. While holding buttons in, pull skate apart to open as shown.



2. Playskool's In-Line Skates are designed with a right and left skate. With child seated, slide right and left feet into skates accordingly. Note: the letters "L" and "R" are located inside skates for proper foot placement.



3. Press in and hold adjustment buttons, then push skate together until it fits in a snug, comfortable position against child's sneaker. Release buttons to lock skate in place.



4. Insert skate strap through buckle and pull strap to tighten. Clamp buckle to secure strap in place.

**CAUTION:** To prevent possible injury, child should wear a safety helmet, and elbow, wrist and knee pads. Read instructions carefully before letting child use My First In-Line Skates.

Product and colors may vary.

©1992, 1997 Hasbro, Inc., Pawtucket, RI 02862 USA. All Rights Reserved.  
®denotes Reg. U.S. Pat. & TM Office. U.S. Pat. No. 5,295,701. **MADE IN MEXICO.**  
50018/50017 Asst.(girls) 50019/50017 Asst. (boys) P/N 43211204

Questions? Call  
**1-800-PLAYSKL**