

NEW KIDS ON THE BLOCK™


PERSONAL

CASSETTE PLAYER


WITH HEADPHONES

Instructions

BATTERY INSTALLATION



1. Slide and lift cover from cassette player.




2. Insert 2 "AA" batteries into battery compartment as shown inside battery compartment and in illustration. Replace cover. (Alkaline batteries are recommended.)


CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturer's instructions.
2. Never mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
3. Always remove exhausted or dead batteries from the product.


OPERATION




1. Place cassette player with photograph side facing up and buttons facing toward you. Swing cassette door up. Insert cassette into cassette compartment with tape end facing you. Close door.




2. Plug headphones jack into headphones outlet.




3. Press PLAY button to start cassette player.



4. Move VOLUME switch left or right to adjust volume to desired level.



5. To advance cassette tape, press FAST FORWARD button.



6. To stop playing in the middle of a tape, press STOP button. Cassette will automatically stop at the end of a tape. To remove cassette tape from cassette player, swing door open. Make sure door is closed when player is not in use.

Limited Warranty on New Kids on the Block™ Cassette Player

Hasbro, Inc. warrants to the original purchaser of this product that the product will be free from defects in material or workmanship for 90 days from the date of original purchase. This warranty does not cover damage resulting from accident, unreasonable use, neglect, improper service, or other causes not arising out of defects in material or workmanship.

To obtain warranty service on your New Kids on the Block Cassette Player, please call our toll free hotline number (1-800-255-5516) and ask for Consumer Service so that we can provide you with instructions. If the unit is returned to us for service, you must pay the postage for mailing it to us. We will pay the cost of returning the product to you.

Please do not return your unit to the retailer. Do not return the unit to any address without authorization from Hasbro, Inc. Consumer Service Department.

During the 90-day warranty period, any defective product will either be replaced (not necessarily with a new product) or repaired at our option without charges to the purchaser.

Post Warranty Repair Policy

After the 90-day warranty period has expired, Hasbro, Inc. will, for a period of one (1) year from the date of purchase, either repair or replace (not necessarily a new product) your New Kids on the Block Cassette Player on the condition that you obtain authorization from the Hasbro Consumer Service Department. Ship the unit prepaid to the address provided along with proof of purchase date and your check or money order in the amount of \$7.50. Hasbro, Inc. shall not be obligated to perform this service if the New Kids on the Block Cassette Player has been abused, misused, improperly serviced, or damaged due to accident.

Hasbro, Inc. will not be held liable for loss of the product or other incidental or consequential costs, expenses, or damages incurred by the original purchaser. Any implied warranties are limited in duration to the 90-day period from the original date of purchase.

This warranty gives you specific legal rights. You may have other rights which vary from state to state.

Before returning your New Kids on the Block Cassette Player for repair, we recommend that you read the instructions carefully and test your product with fresh, strong alkaline batteries.

