



A0021

OVER 18M-4Y




Elmo Cash Register


TO PLAY:

Exploring numbers and counting is so much fun with the Elmo Cash Register!

Use stylus to write name on signature pad!



Press buttons to explore numbers 0-9 and 3 different food items!



Insert play coins* here! They magically appear in drawer!

Swipe "credit card" to clear screen!



Press "open" button to open drawer, and hear a beep sound and fun phrases!

*NOTE: Only play coins included with Elmo Cash Register should be inserted in slot.

SLEEP MODE:

After 20 seconds of inactivity, the Elmo Cash Register will enter sleep mode. To reactivate, just press any key or slide the credit card!

 **x2** 1.5VAA
ALKALINE BATTERIES REQUIRED
DEMO BATTERIES INCLUDED




Troubleshooting:

If the Elmo Cash Register does not play sounds or speak, it may be time to change the batteries.

REPLACE BATTERIES:

Replace demo batteries with alkaline batteries. Phillips/cross head screwdriver (not included) needed to insert batteries. Use screwdriver to loosen screw in battery compartment cover (screw remains attached to cover). Remove cover. Remove and discard demo batteries. Replace with fresh 2 x 1.5V AA size alkaline batteries. Replace cover and tighten screw.



IMPORTANT: BATTERY INFORMATION



CAUTION:

1. TO AVOID BATTERY LEAKAGE
 - a. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
 - b. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
 - c. Remove exhausted or dead batteries from the product.
 - d. Remove batteries if product is not to be played with for a long time.
 - e. Do not short-circuit the supply terminals.
- f. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.
2. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Questions? Call 1-800-327-8264

A0021 PN 7267440000



Product and colors may vary. Retain this information for future reference.
© and/or TM* & © 2012 Hasbro, Pawtucket, RI 02861-1059 USA. All Rights Reserved. TM & © denote U.S. Trademarks.

Sesame Street® and associated characters, trademarks and design elements are owned and licensed by Sesame Workshop. © 2012 Sesame Workshop. All Rights Reserved.

Learn and play at
SesameStreet.org