

NERF®

AGES 8+



CAUTION:

Do not aim at eyes or face. TO AVOID INJURY: Use only darts designed for this product. Do not modify darts or dart blaster.



NOTE: Accessories from this blaster may work on your other NERF®* blasters!



Be sure to read and follow all instructions carefully before using this product.

NOTE: JAM CLEARING DOOR must be fully closed for blaster to fire.




RETALIATOR™*


ASSEMBLY




1. To remove **STOCK**, slide **STOCK RELEASE SWITCH** down.



2. Attach **BARREL EXTENSION** to **MAIN BLASTER UNIT** by sliding into place...




...and twisting 45 degrees to lock.



3. Slide **ASSAULT GRIP** onto bottom of **BARREL EXTENSION**.

LOADING AMMO




Load **DARTS** into the **QUICK RELOAD CLIPS**.

- Be sure **DARTS** are inserted in direction indicated on **CLIP**.
- Insert 1 **DART** at a time and push down.
- Included **CLIP** can hold up to 12 **DARTS**.

Do not insert more than 12 darts.


INSERTING CLIP




1. Pull **SLIDE** all the way back until **READY INDICATOR** is orange; keep in the rearmost position.

2. Insert **CLIP** into **MAIN BLASTER UNIT** (make sure arrow on **CLIP** points away from **TRIGGER**).


FIRING



1. Push **SLIDE** all the way forward to chamber **DART**.




2. Pull trigger to fire




3. To fire again:

- Pull **SLIDE** all the way back, then push all the way forward to chamber another **DART**.
- Pull **TRIGGER** to fire.
- Repeat this step until **CLIP** is empty.

RELOADING




1. Pull **SLIDE** all the way back until **READY INDICATOR** is orange; keep in the rearmost position.




2. Press **CLIP RELEASE BUTTON** and remove **CLIP**.
3. Repeat steps for loading ammo.


CLEARING A JAM



1. If **SLIDE** seems stuck, try pulling the **TRIGGER** first.



2. Check **BARREL** area for a jammed **DART**:
 • Pull **SLIDE** all the way back.
 • Open the **JAM CLEARING DOOR** and remove any jammed **DARTS**.
 • Close **JAM CLEARING DOOR** (must be completely closed or blaster will not fire).



3. Check **CLIP** area for a jammed **DART**:
 • Pull **SLIDE** all the way back.
 • Press **CLIP RELEASE BUTTON** and remove the **QUICK RELOAD CLIP**.
 • Remove any jammed **DARTS**.

4. Replace **CLIP** and push **SLIDE** all the way forward. This should load another **DART**.

NOTE: Blaster will not function unless **JAM CLEARING DOOR** is fully closed.

STORING YOUR BLASTER

NOTE: Do not store blaster cocked and ready to fire.
 • Be sure to unload **DARTS** from blaster before putting it away.



Product and colors may vary.

YouTube and the YouTube logo are trademarks of Google Inc.

®* and/or TM* & © 2011 Hasbro. All Rights Reserved.

TM & © denote U.S. Trademarks.

PATENTED U.S. Pat. Nos. 7287526, 5529050 & Pats. Pend., BR CN

& EC Reg. Des. Apps.

98696

PN 7250400000

Hey NERF Nation!

Join us online and keep up with the latest and greatest news from NERF!



Find us on



WATCH ON



Ask a parent before going online.

Questions? Call 1-800-327-8264