



BE SURE TO READ AND FOLLOW ALL INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT.

CAUTION:

Do not aim at eyes or face. TO AVOID INJURY: Use only darts designed for this product. Do not modify darts or dart blaster.


AGES 6+



RECON CS-6™

INSERT BATTERIES


1. Loosen screw in BATTERY DOOR.
2. Insert fresh 2 x 1.5V "AAA" or R03 size batteries (not included). Alkaline batteries recommended.
3. Replace door and tighten screw.




LOADING AMMO

Load DARTS into QUICK-RELOAD CLIP.


- Be sure DARTS are inserted in direction indicated on CLIP.
- Insert 1 CLIP-SYSTEM DART at a time and push down.
- CLIP can hold up to 6 CLIP-SYSTEM DARTS.




ASSEMBLING RECON CS-6




- 1 Slide/snap Flip-Up Sight on to Blaster until it locks into place.




- 2 Attach STOCK to MAIN BLASTER UNIT (A).
 - To remove STOCK, slide STOCK RELEASE SWITCH down (B).



- 3 Attach Barrel Extension to Main Blaster Unit by sliding extension into place...




- 4 ...and twisting 90 degrees to lock.




- 5 Slide Light Beam onto bottom of Barrel Extension.

INSERTING CLIP


- 1 Pull SLIDE all the way back until READY INDICATOR is orange; keep in the rearmost position.
- 2 Insert CLIP into MAIN BLASTER UNIT (make sure arrow on CLIP points away from TRIGGER).




FIRING



- 1 Push SLIDE all the way forward to chamber DART.



- 2 Pull TRIGGER to launch DART.




- 3 To fire again:
 - Pull SLIDE all the way back, then push all the way forward to chamber another DART.
 - Pull TRIGGER to fire.
 - Repeat this step until CLIP is empty.


x2 1.5V AAA or R03 size NOT INCLUDED BATTERIES REQUIRED

Alkaline batteries recommended. Phillips/cross head screwdriver (not included) needed to insert batteries.

RELOADING




- 1 Before removing CLIP from blaster, pull SLIDE all the way back until READY INDICATOR is orange; keep in the rearmost position.




- 2 Press CLIP RELEASE BUTTON and remove CLIP.
- 3 Repeat steps for loading ammo.


USING THE DUAL-MODE LIGHT BEAM



- 1 Slide POWER SWITCH to ON.




- 2 For low-light illumination, slide BEAM SELECTOR SWITCH to TACTICAL LIGHT position.




- 3 For enhanced targeting, slide BEAM SELECTOR SWITCH to RED DOT position.


USING THE FLIP UP SIGHT




- 1 To hit distant targets, flip up both sights.



- 2 Adjust the FLIP UP SIGHT:
 - Turn disc a quarter turn to the left.
 - Slide disc to desired position.
 - Turn disc to the right to lock in place.
 - Slide up for targets that are farther away, and down for close targets.




- 3 Sight your target:
 - Look through the hole in the disc.
 - Raise BARREL until IRON SIGHT is lined up in the hole and centered on your target.




- 4 For shorter ranges:
 - Flip down both sights.
 - Look along notches on top of disc, lining them up with the top of the IRON SIGHT to center your target.


CLEARING A JAM



- 1 If SLIDE seems stuck, try pulling the TRIGGER first.



- 2 Check BARREL area for a jammed DART:
 - Pull SLIDE all the way back.
 - Open the ACCESS DOOR and remove any jammed DARTS.
 - Close ACCESS DOOR (must be completely closed or blaster will not fire).



- 3 Check CLIP area for a jammed DART:
 - Pull SLIDE all the way back.
 - Press CLIP RELEASE BUTTON and remove the QUICK-RELOAD CLIP.
 - Remove any jammed DARTS.
- 4 Replace CLIP and push SLIDE all the way forward. This should load another DART.

STORING YOUR BLASTER

NOTE: Do not store blaster cocked and ready to fire.

- Be sure to unload DARTS from blaster before putting it away.
- CLIP can be stored in handle of STOCK.

IMPORTANT: BATTERY INFORMATION

⚠ CAUTION:

1. As with all small batteries, the batteries used with this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect. If you reside outside the United States, have the doctor call your local poison control center.
2. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
3. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
4. Remove exhausted or dead batteries from the product.
5. Remove batteries if product is not to be played with for a long time.
6. Do not short-circuit the supply terminals.
7. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
8. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**



Product and colors may vary.
© 2009 Hasbro. All Rights Reserved.
TM & © denote U.S. Trademarks.
U.S. Pat. Nos. 5529050 & 7287526.

21309

PN 7045620000



Not suitable for children under 3 years because of small parts - choking hazard.

NERF.COM
FOR NEW PRODUCTS AND OFFERS
Questions? Call: 1-800-327-8264