


AGES
3+



Here is
another fun
way to play!

After your child
molds an object with
Elmo's friends, he
can match the shape
to the playmat.



TIP!

Removing excess PLAY-DOH compound from the molds is easy. Just roll some compound into a ball. Then, place it in the mold. The leftover compound will stick to the ball.

To Clean

Turn off toy and let
PLAY-DOH compound dry.
Vacuum deposits away.

**NOTICE TO PARENTS: CONTAINS WHEAT.
NONTOXIC. CONFORMS TO ASTM D-4236.**

PN 7145430000


PLAY-DOH and the PLAY-DOH logo are trademarks identifying quality modeling compound products produced exclusively by Hasbro, Inc.

®* and/or TM* & © 2010 Hasbro, Pawtucket, RI 02862 USA. All Rights Reserved. TM & © denote U.S. Trademarks. U.S. Patent No. 671362


Sesame Workshop®, Sesame Street® and associated characters, trademarks and design elements are owned and licensed by Sesame Workshop. © 2010 Sesame Workshop. All Rights Reserved.



The colors in a rainbow are
always in the same order. Red,
Orange, Yellow, Green, Blue,
Indigo and Violet. A great
way to remember this order
is with the name Roy G. Biv.



Red, Orange, Yellow, Green, Blue, Indigo, Violet



123

SESAME STREET

**COLOR
MIXER**



CONTENTS:


Color Mixer™ playset (3 pieces),
playmat, plastic scooper, instructions
and 3 three-ounce cans of PLAY-DOH®* Brand
Modeling Compound (Net wt. 9 oz., 255 g).

BATTERIES REQUIRED
x2
1.5VAA or R6 size
NOT INCLUDED
Alkaline batteries recommended. Phillips/cross head
screwdriver (not included) needed to insert batteries.



To Insert Batteries

Using a Phillips/cross head screwdriver (not included), loosen screw in battery compartment cover (screw stays attached to cover). Insert 2 x 1.5V "AA" or R06 size batteries (not included). Alkaline batteries recommended. Replace cover and tighten screw.



IMPORTANT: BATTERY INFORMATION




CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.


To assemble

Attach large mixer piece into the base as shown.

Attach Elmo piece into place along the hinges as shown.



Before you begin, move switch to the ON position.



Elmo has three play modes:

Mix colors in Mode 1.


Push button to pop open lid.

Use the plastic scooper to measure out two colors of PLAY-DOH compound and place them in the mixer. For best results, place PLAY-DOH on red dots.

Then close the lid and crank the handle.

When the song finishes press the button to release the lid and reveal the new color.


For a deeper shade, repeat.



Find colors in Mode 2.

Your child can spin the center mold base to select a color.

When the mold base stops on that color, Elmo will talk about the color.



That's a green apple!



Mold objects in Mode 3.

Choose a mold. Load with PLAY-DOH compound as shown.

Close the stamper lid and press down to mold the object.

