


PLAYSKOOL

123
SESAME STREET

OVER 18M-4Y

Hide 'n Seek Pals™



Note to Consumer:

This toy is packaged in "TRY ME" mode. Slide the Power Switch to "ON" position for the full range of features.



Learn and play at
SesameStreet.org

32717



Product and colors may vary. Retail these instructions for future reference.

©* and/or TM * & © 2011 Hasbro. All Rights Reserved. TM & © denote U.S. Trademarks.

Sesame Workshop®, Sesame Street® and associated characters, trademarks and design elements are owned and licensed by Sesame Workshop. © 2011 Sesame Workshop. All Rights Reserved.

P/N 7170960000

x2 BATTERIES INCLUDED
 1.5V AA or R6 size

Replace with 2 x 1.5V "AA" or R6 size batteries.
 Alkaline batteries recommended. Phillips/cross head screwdriver (not included) needed to replace batteries.




TO PLAY:

Pull lever on the side of the playhouse. Elmo will ask who's behind the windows.

To open the windows, simply press the buttons noted below. Elmo will identify the friend behind each window.

Close the windows to play memory mode. Elmo will ask if you remember where his friends are hiding.




Troubleshooting:

If you are having trouble playing the game, make sure to switch the ON/TRY ME switch from TRY ME into the ON position.

TO REPLACE BATTERIES:

Use a Phillips/cross head screwdriver (not included) to loosen screw in battery compartment cover (screw remains attached to cover). Remove cover. Remove and discard old batteries. Replace with fresh 2 x 1.5V "AA" or R6 size batteries. (Alkaline batteries recommended.) Replace cover and tighten screw.



IMPORTANT: BATTERY INFORMATION

⚠ CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.