



# BRUCE WAYNE™ Street Jet™

INSTRUCTIONS

BATMAN and all related elements are the property of DC Comics Inc. TM and © 1993 All Rights Reserved. Printed in Mexico




© Kemper Products, A Division of Tonka Corporation, Cincinnati, Ohio 45202


63551

**1** Apply labels to vehicle using the numbers on the label sheet and this illustration as a guide.


Top View




Front View 8




Rear View 9



**2.** Open cockpit by lifting up the canopy.




**3.** Pull back on rear spoiler to open launcher compartments and expose secret compartment inside of vehicle. Load projectiles into launchers.



**4.** Place your BATMAN® figure feet first and with his arms down into secret compartment seat. Top bar of bracket should go between figure's ears as shown. (Fits most figures.)




**5.** Slide spoiler forward to conceal BATMAN™ figure.




Lower launchers to horizontal positions and then snap launcher compartments shut.

**7.** At the first sign of danger, pull back on the spoiler to “change” Bruce Wayne™ into BATMAN® and expose launchers for fire power.



**6.** After concealing BATMAN™ figure, fasten Bruce Wayne™ figure into the waist clip in the backseat. Close canopy.



**8.** Tilt launchers up and fire projectiles by pressing the buttons on the sides. Remember, always lower launchers to horizontal positions before closing the launcher compartments.

