



BRUCE WAYNE™ Street Jet™

INSTRUCTIONS

BATMAN and all related elements are the property of DC Comics Inc. TM and © 1993 All Rights Reserved. Printed in Mexico




Kemper®

© Kenner Products, A Division of Tonka Corporation, Cincinnati, Ohio 45202


63551

1 Apply labels to vehicle using the numbers on the label sheet and this illustration as a guide.


Top View




2. Open cockpit by lifting up the canopy.



3. Pull back on rear spoiler to open launcher compartments and expose secret compartment inside of vehicle. Load projectiles into launchers.




4. Place your BATMAN® figure feet first and with his arms down into secret compartment seat. Top bar of bracket should go between figure's ears as shown. (Fits most figures.)




70000700

5. Slide spoiler forward to conceal BATMAN™ figure.




Lower launchers to horizontal positions and then snap launcher compartments shut.

7. At the first sign of danger, pull back on the spoiler to “change” Bruce Wayne™ into BATMAN® and expose launchers for fire power.



6. After concealing BATMAN™ figure, fasten Bruce Wayne™ figure into the waist clip in the backseat. Close canopy.



8. Tilt launchers up and fire projectiles by pressing the buttons on the sides. Remember, always lower launchers to horizontal positions before closing the launcher compartments.

