

The jump rope that really makes bubbles!

Bubblin' JUMP ROPE

Includes jump rope and removable handles.
Dishwashing liquid required (not included).

Dear Friend,
Get ready for a bouncy, bubbly good time with delightful, easy-to-use Bubblin' Jump Rope from Hasbro. Please read the instructions below and carefully follow each step so that you get maximum enjoyment from this fun-filled product. Happy hopping!






HOW TO MAKE BUBBLES

1. Pour water into each handle up to line marked "water."
2. Add any quality dishwashing liquid up to line marked "soap." Be sure water goes in *before* dishwashing liquid for better mixing.

IMPORTANT:
Only fill the handles to the lines to allow room to make foam.

3. To attach cap on end of rope to handle, hold cap and twist on the handle. Repeat for other cap and handle.
4. Holding handles upright, shake vigorously until each one is filled with foam. With handles still in upright position, squeeze handles to force foam into the bubble chambers. Continue to squeeze handles until foam can be seen in the bubble chamber holes.

5. Now you're ready for a bubblin', jumpin' good time! As you begin to jump and rotate the rope, squeeze the handles to keep the foam moving into the bubble chambers. For best results, jump at medium speed (about 1 jump per second). It'll take 2 to 5 revolutions before bubbles start to appear. With continuous jumping, the rope should bubble for approximately 2 minutes.



9800 ASST.





FOR BEST BUBBLING . . .

Avoid the wind.
Foggy, cloudy days are especially good for bubble making.
Bubbles tend to last longer in humid weather.

HELPFUL HINTS

1. To remove a handle from the cap on the end of the rope, hold the cap stationary and twist the handle off. Repeat this method when twisting the handle onto the cap. Be sure caps are screwed on tightly to prevent leakage.
2. Be sure each handle is completely filled with foam before jumping.
3. Because it is the foam that creates bubbles – not the liquid – always check to see that there is a good supply of foam in the handles and bubble chambers.
4. Bubbles should appear after about 2–5 jumping revolutions. If bubbling doesn't begin after 5 revolutions, slow your jumping down to about one revolution per second.
5. Slower jumping with "big" arm swings create the most bubbles.

TO MAKE A LARGE AMOUNT OF PREMIXED BUBBLE SOLUTION

1. Pour one half cup of quality dishwashing liquid into a 2–quart pitcher.
2. Add 5 cups of water and stir.
3. Fill jump rope handles with solution up to the line marked "soap" and follow steps 3, 4 and 5.

PLAY IT SMART

- ADULT SUPERVISION IS NECESSARY.
- Bubble soap is slippery. Avoid play on smooth pavements and metal gratings. Spilled dishwashing liquid also makes for a slippery situation and can cause lawn discoloration, so please be careful.

TO CLEAN AND STORE

1. Rinse handles (inside and out) and rope with water.
2. To clean inside of bubble chamber, fill handles with water and thread them onto ends of rope. Squeeze each handle so that water is forced through the chamber.
3. To keep the colors bright, store your jump rope away from sunlight, which can cause the colors to fade.