




⚠ WARNING:

CHOKING HAZARD—Small parts.
Not for children under 3 years.



INSTRUCTIONS:

BEGIN by throwing ball in the air. The player whose side it lands on kicks the ball first.

PLAY is fast and continuous, with players trying to knock down each other's goal cones with the ball. You can use any part of your body (except hands) to defend your goals. You can not purposely step on the bungee cord at any time to intentionally stop the play, and can not cross the midfield stripe and enter your opponent's zone.

SCORE a goal by knocking down one of your opponent's goal cones. If you accidentally knock down your own goal cone, your opponent is awarded a point. Game is non-stop until a goal cone is knocked down. Then the game stops and goal cone set back up. The person scoring the point kicks from his side, starting the play again. The first player to score 10 goals wins!

Kenner

© 1994 Kenner, a division
of Tonka Corporation,
Cincinnati, Ohio 45202




Kickback Soccer™ Game

Ages 4 and up


NOTE: Play only in an open area away from small children. ASSEMBLY REQUIRED Hammer and air pump needed.

HOW TO SET UP THE PLAYING FIELD




1. Feed strap through underside slots in anchor plate.

2. Position the anchor plate at the center of the playing field. With hammer, an adult should drive the three large stakes into the holes in the anchor plate to secure it to the ground. Stretch the midfield line straps out to their full length (as indicated in the drawing below) and an adult should secure them to the ground with the small stakes.




ANCHOR PLATE


MIDFIELD LINE STRAPS



3. Locate inflation needle. An adult should moisten needle and slowly insert it straight into the ball's inflation hole. Inflate ball with hand air pump, using the circular cutout insert to help you correctly inflate the ball to its proper size. **DO NOT OVERINFLATE.**




4. Thread the bungee cord through the end loops of the ball net to create a bag for the ball. Thread one end of the bungee cord through the loop on the cord's opposite end as shown. Place the ball in the net and pull on the looped bungee cord to secure it in the net.



5. Insert the loose end of the bungee cord through the hole in the anchor plate post as shown. Place the loop over the post. Pull cord to tighten.

6. Measure out the rest of the playing field and place the goal cones at the corners as indicated.



NOTE: Play only in an open area away from small children. Now you are ready to play. Read the instructions for play on the reverse side of this sheet.